




OpenScape Desk Phone IP 35G OpenScape Desk Phone IP 35G Eco OpenScape Business

User Guide HFA (icon version)

A31003-D3530-U103-3-7619

Our Quality and Environmental Management Systems are implemented according to the requirements of the ISO9001 and ISO14001 standards and are certified by an external certification company.

Important information

	<p>For safety reasons, the telephone should only be supplied with power:</p> <ul style="list-style-type: none">• using the original power supply unit. Part number: L30250-F600-C14x (x: 1=EU, 2=UK, 3=US) or• in a LAN with PoE (Power over Ethernet), which complies with the IEEE 802.3af standard.
	<p>Never open the telephone or a key module. Should you encounter any problems, consult your administrator.</p>
	<p>Use only original accessories. The use of other accessories may be hazardous and will render the warranty, extended manufacturer's liability and the CE marking invalid.</p>

Trademarks



The device conforms to the EU Directive 1999/5/EC as attested by the CE marking.

All electrical and electronic products should be disposed of separately from the municipal waste stream via designated collection facilities appointed by the government or the local authorities.



The correct disposal and separate collection of your old appliance will help prevent potential negative consequences for the environment and human health. It is a precondition for reuse and recycling of used electrical and electronic equipment.

For more detailed information about disposal of your old appliance, please contact your city office, waste disposal service, the shop where you purchased the product or your sales representative.

The statements quoted above are only fully valid for equipment that is installed and sold in the countries of the European Union and is covered by the European Directive 2002/96/EC. Countries outside the European Union may have other regulations regarding the disposal of electrical and electronic equipment.

Location of the telephone

- The telephone should be operated in a controlled environment with an ambient temperature between 5°C and 40°C.
- To ensure good speakerphone quality, the area in front of the microphone (front right) should be kept clear. The optimum speakerphone distance is 50 cm.
- Do not install the telephone in a room where large quantities of dust accumulate; this can considerably reduce the service life of the telephone.
- Do not expose the telephone to direct sunlight or any other source of heat, as this is liable to damage the electronic components and the plastic casing.
- Do not operate the telephone in damp environments, such as bathrooms.

Software update



During a software update, the phone must not be disconnected from the power supply unit, the LAN line or the phone line.

An update action is indicated by messages on the display and/or by flashing LEDs.

Product support on the Internet

Information and support for our products can be found on the Internet at:

<http://www.unify.com>.

Technical notes, current information about firmware updates, frequently asked questions and lots more can be found on the Internet at:

<http://wiki.unify.com/>.

Contents

Important information 3

Trademarks	3
Location of the telephone	4
Software update	4
Product support on the Internet	4

General information 10

About this manual	10
Service	10
Intended use	11
Telephone type	11
Speakerphone quality and display legibility	11
Voice encryption	11
Multi-line telephone, executive/secretary functions	12
Group functions	12

Getting to know the OpenScape Desk Phone 13

The user interface of your OpenScape Desk Phone IP 35G	13
Navigation keys	15
Programmable function keys	15
Dialpad	16
Display	16
Idle mode	16
Mailbox	17
Messages	17
Voicemail	17
Call list	18
Menu	19
Settings	19
Telephone user menu	20
Control and monitoring function	20
OpenStage Manager	20
Features	20
Ports on the underside of the phone	21
Using network ports more efficiently	21

Basic functions 22

Accepting a call	22
Accepting a call via the handset	22
Accepting a call via the loudspeaker (speakerphone mode)	23
Accepting a call via the headset	23
Switching to speakerphone mode	23
Switching to the handset	24
Open listening in the room during a call	24
Turning the microphone on and off	24
Ending the call	24

Making calls	25
Off-hook dialing	25
On-hook dialing	25
Dialing with the headset connected	25
Dialing with redial keys	26
Redialing a number	26
Rejecting calls	26
Calling a second party (consultation)	27
Switching to the held party (alternating)	27
Transferring a call	27
Forwarding calls	28
Using variable call forwarding	28
Using call forwarding no reply (CFNR)	29
Call forwarding in the event of telephone failure (CFSS)	30
Call forwarding in the carrier network and forwarding multiple subscriber numbers (MSN) (not for U.S.)	31
Using callback	32
Saving a callback	32
Accepting a callback	32
Viewing and deleting a saved callback	33
Enhanced phone functions	34
Accepting calls	34
Picking up a specific call for your colleague	34
Accepting calls via the headset	34
Using the speakerphone	35
Accepting calls from the entrance telephone and opening the door	35
Making calls	37
En-bloc sending/correcting numbers	37
Using the caller list	38
Calling a subscriber from the personal phonebook	39
Calling a subscriber from the corporate directory	39
Calling a subscriber from the internal system phonebook	39
Using the LDAP directory from the system phonebook	40
Making calls using system speed-dial numbers	42
Dialing with speed-dial keys	42
Talking to your colleague with a speaker call	43
Talking to your colleague with discreet calling	44
Automatic connection setup (hotline)	44
Reserving a trunk	44
Assigning a station number (not for U.S.)	45
Associated dialing/dialing aid	45
During a call	46
Using call waiting (second call)	46
Preventing and allowing call waiting (automatic camp-on)	47
Turning the call waiting tone on and off	47
Saving a number	47
Parking a call	48
Holding external calls	49
Conducting a conference	50
Activating tone dialing/DTMF suffix dialing	51
Recording a call	52
Transferring a call after a speaker call announcement in a group	52
Sending a trunk flash	53

If you cannot reach a destination	53
Call waiting (camp-on)	53
Busy override - joining a call in progress	53
Using night answer	54
Programming the function keys	55
Configuring function keys	55
Overview of functions.	56
Programming a procedure key	58
Configuring redial keys	59
Deleting function key programming.	59
Displaying and assigning call charges	60
Displaying call charges (not for U.S.)	60
Displaying call charges for another telephone (not for U.S.).	60
Dialing with call charge assignment	61
Privacy/security	62
Voice encryption	62
Displaying status	62
Notes on voice encryption	63
Turning ringer cutoff on and off	63
Activating/deactivating "Do not disturb"	64
Caller ID suppression	64
Monitoring a room	65
Trace call – identifying anonymous callers (not for U.S.)	65
Locking the telephone to prevent unauthorized use	66
Locking another telephone to prevent unauthorized use	66
Saving your PIN code	67
More functions/services	68
Appointment reminder function	68
Saving a timed reminder	68
Using timed reminders	69
Sending a message	69
Creating and sending a message	69
Viewing and editing incoming messages	70
Leaving an advisory message.	70
Deleting advisory messages	71
Displaying the number of waiting calls/overload display	71
Using another telephone like your own for a call	71
Using a mobile connection at a random phone.	72
Mobility variants	72
Logging on to the "guest telephone"	73
Moving the connection to the next telephone	74
Logging off from the "guest telephone"	74
Fax details and message on answering machine	75
Resetting services and functions (system-wide cancelation for a telephone)	76
Activating functions for another telephone	76
Using system functions from outside DISA (Direct Inward System Access)	77
Using functions in ISDN via code dialing (keypad dialing)	78

Controlling connected computers/programs/telephone data service	79
Communicating with PC applications over a CSTA interface	80
Controlling relays (only for HiPath 3000)	80
Sensors (HiPath 33x0/35x0 only)	81
Paging persons (not for U.S.)	81

Phonebooks 82

Personal phonebook	82
Creating a new contact	82
Editing a contact	82
Deleting a contact	83
Deleting all contacts	83
Searching for a contact	84
Corporate directory	85
Searching for a contact	85
Advanced phonebook editing	86
Quick search	87

Making calls in the team/executive/secretary configuration . . . 88

Lines	88
Line utilization	88
Line seizure	88
Line/trunk keys	89
Accepting calls with the trunk keys	89
Dialing with trunk keys	89
Placing a call on hold on a trunk key and retrieving the held call	90
Making calls on multiple lines alternately	90
MULAP conference release	90
Direct station selection keys	91
Using DSS keys to accept calls	91
Calling a team member directly	91
Transferring a call in progress	92
Picking up a call for another team member	92
Forwarding calls on trunks	92
Transferring calls directly to the executive phone	94

Using team functions 95

Activating/deactivating a group call	95
Picking up a call for another member of your team	97
Ringling group	97
Uniform Call Distribution (UCD)	98

Special functions in the LAN 100

Leaving hunt group/group call	100
Setting up "follow me" call forwarding	101
Using night answer	102
Ringling group	103
Controlling relays (only for HiPath 3000)	104
Opening a door	104

Individual phone configuration	105
Setting contrast	105
Audio	105
Setting the ringer mode	105
Adjusting audio settings	106
Adjusting the receiving volume during a call	106
Adjusting the ring volume	106
Adjusting the ringer pitch	106
Adjusting the attention ring volume	106
Adjusting the speakerphone to the room acoustics	107
Language for system functions	107
Setting local ring tones	108
Setting headset port use	109
Changing the user password	110
Network information	111
 Testing the phone	 112
Testing the phone's functionality	112
Checking the key assignment	112
 Differing display views in a HiPath 4000 environment	 113
 Web interface	 114
General	114
Launching the web interface	114
Administrator Pages	114
User Pages	115
User menu	116
 Fixing problems	 117
Responding to error messages	117
Contact partner in case of problems	118
Troubleshooting	118
Care and cleaning instructions	118
Labeling keys	118
 Local user menu	 119
Opening the user menu on the phone	119
User menu display	119
 Index	 121
 Overview of functions and codes (alphabetical)	 126

General information

About this manual


This document contains general descriptions of the technical options, which may not always be available in individual cases. The required features must therefore be individually defined in the terms of the contract.

If a particular function on your phone is not available to you as described, this may be due to one of the following reasons:

- The function is not configured for you and your telephone. Please contact your system administrator.
- Your communication platform does not feature this function. Please contact your Unify sales partner for information on how to upgrade.

This user guide is intended to help you familiarize yourself with the OpenScape Desk Phone and all of its functions. It contains important information on the safe and proper operation of the OpenScape Desk Phone. These instructions should be strictly complied with to avoid operating errors and ensure optimum use of your multifunctional telephone.


These instructions should be read and followed by every person installing, operating or programming the OpenScape Desk Phone.

 For your own protection, please read the section dealing with safety in detail. Follow the safety instructions carefully in order to avoid endangering yourself or other persons and to prevent damage to the unit.

These operating instructions are designed to be simple and easy to understand, providing clear step-by-step instructions for operating the OpenScape Desk Phone.

Administrative tasks are dealt with in a separate manual. The Quick Reference Guide contains quick and reliable explanations of frequently used functions.

Service

 The Unify service department can only help you if you experience problems or defects with the phone itself.
Should you have any questions regarding operation, your specialist retailer or network administrator will gladly help you.
For queries regarding connection of the telephone, please contact your network provider.

If you experience problems or defects with the phone, please dial the service number for your country.

Intended use

The OpenScape Desk Phone is a desktop or wall-mounted unit designed for voice transmission and for connection to a LAN. Any other use is regarded as unintended.

Telephone type

The identification details (exact product designation and serial number) of your telephone can be found on the nameplate on the underside of the base unit.

Specific details concerning your communication platform can be obtained from your administrator. Please always have this information to hand when you contact our service department regarding faults or problems with the product.

Speakerphone quality and display legibility

- To ensure good speakerphone quality, the area in front of the microphone (front right) should be kept clear. The optimum speakerphone distance is 50 cm.
- Proceed as follows to optimize display legibility:
 - Turn the phone to tilt the display to ensure you have a frontal view of the display and avoid light reflexes.
 - Adjust the contrast as required → Page 105.

Voice encryption

On OpenScape Business (from R 4), your OpenScape Desk Phone IP 35 G supports voice encryption from software release 3 (V1 R0.xxxx). This allows you to use your OpenScape Desk Phone to conduct calls without the risk of eavesdropping. Voice transmission is encrypted and then decrypted again on the call partner's phone and vice versa.

If "Secure Mode" is enabled on your phone and a connection is established to a phone that does not support voice encryption, the call is not encrypted and is thus not secure.

Your administrator can define in your communication system whether you are notified of unencrypted calls and how → Page 63.

Multi-line telephone, executive/secretary functions

Your OpenScape Desk Phone IP 35 G is a "multi-line telephone". This means that multiple lines can be configured by your administrator, which is not the case with single-line phones. Each line is assigned an individual phone number that you can use to make and receive calls.

The programmable keys function as line keys on multi-line phones → Page 89.

When using a multi-line phone to make and receive calls, certain particularities must be taken into account → Page 89 ff.

The executive-secretary configuration is a special case. This is a multi-line telephone with special features (e.g. "Ring transfer" and "Pick up call"), configured especially for executive/secretary use → Page 88 ff.

Group functions














For even more efficient telephone functionality, your administrator can configure various team functions such as call pickup, hunt groups and call distribution groups.

Getting to know the OpenScape Desk Phone

The following sections describe the most frequently used controls and displays.

The user interface of your OpenScape Desk Phone IP 35G



1	You can make and receive calls as normal using the handset .
2	The display provides intuitive support for telephone operation (two lines with up to 33 characters each).
3	<p>The function keys (cannot be reprogrammed) allow you to call up the following frequently used functions during a call:</p> <p>: Open the mailbox → Page 17.</p> <p>: Open the menu → Page 19.</p> <p>: Activate/deactivate the speakerphone function.</p> <p>: Activate/deactivate the headset function.</p> <p> and : Increase/reduce the volume of the loudspeaker/headset; set the contrast lighter and darker.</p> <p>: Activate/deactivate the microphone. This function is useful to prevent the other party from listening in under certain circumstances, for example when consulting with someone else in the room or in case of annoying background noise.</p> <p>: Transfer a call to another subscriber.</p> <p>: Enable access to the conference functions.</p> <p>: Hold or retrieve the active call.</p>
4	You can use the navigation keys to open the idle menu → Page 16 for example or to scroll forward or back in menus or execute an action.
5	The dialpad can be used to enter phone numbers and write text.
6	<p>Depending on how they are programmed, you can use the keys as follows:</p> <ul style="list-style-type: none"> • Function keys • Redial/Direct station selection key <p>Each key can be programmed with one function. You can also use the preassigned functions:</p> <ul style="list-style-type: none"> •  •  • 
7	Incoming calls and new voicemails are visually signaled via the call display .

Navigation keys

This control allows you to move between input fields, navigate in lists and menus or open the idle menu. You use the OK button to confirm options and launch functions:



Key	Functions when key is pressed
	Open the idle menu → Page 16 or browse back in the menu.
	Open the idle menu → Page 16 or browse back in the menu.
	Open the idle menu → Page 16 or browse forward in the menu.
	Perform action

Programmable function keys

Your OpenScape Desk Phone IP 35G has three fixed function keys (with LED), which you can reprogram with different functions or phone numbers at any time.



Preassignment of function keys:

- (Release Call)
- (Redial)
- can include the following entries (depending on the configuration):
Unanswered calls?, internal or external, or all external calls, both answered and unanswered.

Depending on how they are programmed, you can use the keys as follows:

- Function keys → Page 55
- Redial keys → Page 59

Each key can be programmed with one function.

The status of a function is shown by the LED display for the corresponding function key.

You will find information on the labeling of the function keys on → Page 118


Meaning of LED displays on function keys

LED		Meaning of function key
	Off	The function is deactivated.
	Flashing ¹	Indicates the function status.
	On	The function is activated.

¹ In this manual, flashing keys are identified by this icon, regardless of the flashing interval. The flashing interval represents different statuses, which are described in detail in the corresponding sections of the manual.

Dialpad

You can only use the digits 1 to 9 and 0 as well as the * and # characters when dialing a number. In cases where text input is possible, you can use the dialpad to input text, punctuation and special characters in addition to the digits 0 to 9 and the hash and asterisk symbols. To do this, press the numerical keys repeatedly.

Example: To enter the letter "h", press the number  key on the keypad twice.



To enter a digit in an alphanumerical input field, hold down the relevant key.

Alphabetic labeling of dial keys is also useful when entering vanity numbers (letters associated with the phone number's digits as indicated on the telephone spell a name, e.g. 0700 - PATTERN = 0700 - 687837).


Display

Your OpenScape Desk Phone IP 35G comes with a black-and-white LCD display. Adjust the contrast to suit your needs (→ Page 105).




Idle mode

If there are no calls taking place or settings being made, your OpenScape Desk Phone IP 35G is in idle mode.

Example:



Idle menu

Press one of the navigation keys    → Page 15 in idle mode to open the idle menu. You can call up various functions here. The idle menu includes selected functions from the Program/Service menu → Page 19.

The idle menu may contain the following entries:


- Caller list
- Forwarding on
- Lock phone
- DND on¹
- Advisory msg. on
- Ringing cutoff on
- Send message
- View sent message²
- View callbacks³
- Phonebook (system phonebook)
- HF answerback on
- Suppress call ID
- Waiting tone off
- DISA internal

1. Must be activated by the administrator.

2. Only appears when there are messages that the recipient has not yet viewed.

3. Only appears if callback requests are saved.

Mailbox

Depending on your communication platform and its configuration (consult your administrator), you can use the  key to access messages from services such as HiPath Xpressions in addition to messages received.


Messages


You can send short text messages to individual internal stations or groups. In idle mode (→ Page 16), the following signals alert you to the presence of new messages:

-  The key LED lights up.
- "Messages received" is displayed.

Press the  key.

Example:




 For a description of how to edit the entries → Page 70.

Voicemail

Press the  key.

If your system is appropriately configured, you can call the voice mailbox directly and immediately play back the messages saved.

If your telephone is connected to a voicemail system (such as Entry Voice Mail), the  key will also light up to alert you to any messages that have arrived.

An appropriate message also appears on the display (for instance, in Entry Voice Mail: "X new messages").

To listen to your voicemail, follow the instructions on the display.

Call list

If you are unable to accept an external or internal call, the call attempt is stored in the caller list. Answered calls can also be saved (consult your administrator).


Your telephone stores up to ten calls in chronological order. Each call is assigned a time stamp. The oldest entry not yet deleted in the list is displayed first. Multiple calls from the same caller do not automatically generate new entries in the caller list. Instead, only the most recent time stamp for this caller is updated and its number incremented.

The caller list is automatically displayed → Page 38 in the idle menu → Page 16.

Callers with suppressed numbers cannot be saved in the call list.


Information is displayed regarding the caller and the time at which the call was placed.

Example:




For a description of how to edit the call lists → Page 38.

Menu

Use the  menu key to access the following options:

- Program/Service menu for your communication system
- Personal (local phonebook)
- Corporate (corporate directory)
- User (local telephone settings for users)
- Administrator (local telephone settings for administrators)


The menu key LED remains red as long as you are in this menu.



Settings





You can use the Settings option to access your communication system's extensive functions.

Example:



The menu structure consists of several levels. The first line in this structure shows the menu currently selected while the remaining lines show the options for this menu. The arrow next to an entry indicates the availability of additional options for this entry.





Opening the Settings

Press the  menu key, choose the Program/Service menu using the   keys and confirm with .

Telephone user menu

You can configure settings for your OpenScape Desk Phone here.

Opening the user menu

To access: Press the  key. Select the "User" option with the   keys and confirm with .

If necessary, enter the user password → Page 110.

The menu structure contains several levels.



You can also configure some of the settings using the web interface → Page 114 of your OpenScape Desk Phone.

Control and monitoring function

A control or monitoring function can be activated on your phone for service purposes by remote maintenance.

Control function

Your administrator has the option to activate and deactivate features of the phone via remote maintenance. During maintenance, the handset, microphone, loudspeaker and headset are deactivated. You are additionally informed on the display that the control function is active.

Monitoring function

In order to detect malfunctioning of a phone, for example, your administrator can install a monitoring function. You can use your phone as normal during monitoring. However you will first be informed about the operation with a message on the display and prompted to allow monitoring.

OpenStage Manager

The program offers you an additional means of adapting your telephone to your personal needs. Further information is available at:

http://wiki.unify.com/wiki/OpenStage_Manager.


Features

- Phonebook management
- Synchronization of contacts



Contact your administrator for the latest version of OpenStage Manager. The range of features is dependent on the type of telephone.

Ports on the underside of the phone




Using network ports more efficiently

The OpenScape Desk Phone IP 35G has a built-in Ethernet switch. This means that you can connect a PC to the LAN directly via the phone. The option for connecting the telephone and PC must first be activated on the telephone by your administrator.



Using this connection option saves one network port for each switch used and requires fewer or shorter network cables when arranged correctly.


Basic functions

 Please read the introductory chapter "Getting to know the OpenScape Desk Phone IP" → Page 13 carefully before performing any of the steps described here on your phone.

Accepting a call

Special default ring signaling is set for your telephone:

- When you receive an internal call, your telephone rings once every four seconds (single-tone sequence).
- When you receive an external call, your telephone rings twice in rapid succession every four seconds (dual-tone sequence).
- When you receive a call from the entrance telephone, your telephone rings three times in rapid succession every four seconds (triple-tone sequence).
- If a call is waiting, you hear a short tone (beep) every six seconds.

 Your administrator can adjust the ring cadence for external and internal calls for you. In other words, different ring cadences can be set for different internal callers.



The number or the name of the caller appears on the display.

Accepting a call via the handset

The phone rings. The caller appears on the screen¹.

Lift the handset.

Raise or lower the volume. Keep pressing the key until the desired volume is set.

if nec.  or 

1. Pay attention to the notes on voice encryption → Page 63.

Accepting a call via the loudspeaker (speakerphone mode)


Suggestions for using speakerphone mode:

- Tell the other party that you are using speakerphone mode.
- The speakerphone works best at a low receiving volume.
- The ideal distance between the user and the telephone in speakerphone mode is about 50 cm (approx. 20 inches).

The phone rings. The caller appears on the screen¹.

Press the key shown. The LED lights up.

Raise or lower the volume. Keep pressing the key until the desired volume is set.



Accepting a call via the headset


Prerequisite: A headset is connected.

 Make sure your headset port is set up properly → Page 109.

The phone rings. The  key flashes.

Press the key shown.

Adjust the call volume.




Switching to speakerphone mode

Prerequisite: You are conducting a call via the handset.

Hold down the key and replace the handset. Then release the key and continue the call.

Adjust the call volume. Keep pressing the key until the desired volume is set.




U.S. mode

If the country setting is set to U.S. (consult your administrator), you do not have to hold down the loudspeaker key when replacing the handset to switch to speakerphone mode.


Press the key shown.

Replace the handset. Proceed with your call.

Adjust the call volume. Keep pressing the key until the desired volume is set.



1. Pay attention to the notes on voice encryption → Page 63.



Switching to the handset

Prerequisite: You are conducting a call in speakerphone mode.

Lift the handset. Proceed with your call.

Open listening in the room during a call

You can let other people in the room join in on the call. Let the other party know that you have turned on the speaker.

Prerequisite: You are conducting a call via the handset.

Activating



Press the key shown. The LED lights up.

Deactivating



Press the key shown. The LED goes out.

Turning the microphone on and off

To prevent the other party from listening in while you consult with someone in your office, you can temporarily switch off the handset microphone or the handsfree microphone. You can also switch on the handsfree microphone to answer an announcement via the telephone speaker (speaker call → Page 35).

Deactivating the microphone



Press the "Mute" key.

Activating the microphone



Press the illuminated "Mute" key.

Ending the call



Press the key shown.

or



Press the illuminated key.

or



Replace the handset.

Making calls

Off-hook dialing



Lift the handset.

Internal calls: Enter the phone number.

External calls: Enter the external code and the phone number¹.

The called party does not answer or is busy:



Replace the handset.

On-hook dialing



Internal calls: Enter the phone number.

External calls: Enter the external code and the phone number¹.



Your system may also be programmed so that you have to press the "internal" key before you dial the internal number. You then do not have to enter an external code to call the external party (automatic trunk seizure/prime line is not active; consult your administrator).

The other party answers with speaker:



Lift the handset.

or

On-hook dialing: Speakerphone mode.

The called party does not answer or is busy:



Press the key shown. The LED goes out.

Dialing with the headset connected

Prerequisite: The headset is connected.



Internal calls: Enter the phone number.

External calls: Enter the external code and the phone number.



The headset key lights up.

The connection is set up as soon as your input is complete¹.



Make sure your headset port is set up properly → Page 109.

1. Pay attention to the notes on voice encryption → Page 63.

Dialing with redial keys

Prerequisite: You have saved a number on a redial key → Page 59.

Press the key with the saved number¹.

If the number is saved at the second level, press the "Shift" key first.



You can also press the redial key during a call and automatically initiate a callback → Page 27.

Redialing a number

The last ten external phone numbers dialed are stored automatically.



If this feature is configured (consult your administrator), account codes entered are also saved → Page 61.

You can redial them simply by pressing a key.

Displaying and dialing saved station numbers

Prerequisite: The  key is not reprogrammed.


Press the key shown.

Keep confirming until the phone number you want appears.

Select and confirm the option shown¹.

Rejecting calls

You can reject calls you do not wish to take. The call is then signaled on another definable telephone (consult your administrator).

Prerequisite: The  key is not reprogrammed. The phone rings. The caller appears on the screen.

Press the key shown.

If a call cannot be rejected, your telephone will continue to ring. The message "currently not possible" is displayed (e.g. in the case of recalls).

1. Pay attention to the notes on voice encryption → Page 63.

Consultation?



Return to held call?

or

Quit and return?

Toggle/Connect?

Conference?

or



Leave conference?

Consultation?



or

Transfer?

Calling a second party (consultation)

You can call a second party while a call is in progress. The first party is placed on hold.

Confirm the option shown.

Call the second party¹.

Return to the first party, the second party does not answer:

Confirm the option shown.

End the consultation:

Select and confirm the option shown.

Switching to the held party (alternating)

Select and confirm the option shown¹.

Combining the call parties in a three-party conference

Select and confirm the option shown.

Press the key shown.



If voice encryption is not activated or not available on a conference party's phone, the entire conference is not secure. It may be indicated that the call is not secure. For more information on conferences, see → Page 50.

Leaving a conference

Select and confirm the option shown.

Transferring a call

If the person you are speaking to wants to speak to another colleague of yours, you can transfer the call to that colleague.

Confirm the option shown.

Enter the number of the party to whom you want to transfer the call.

Announce the call, if necessary.

Press the key shown. The person you were speaking with is now connected to the desired party.

Replace the handset.

Select and confirm the option shown².

1. Pay attention to the notes on voice encryption → Page 63.

2. "Differing display views in a HiPath 4000 environment" → Page 113

Forwarding calls

Using variable call forwarding

You can immediately forward internal or external calls to different internal or external telephones (destinations). (External destinations require special configuration in the system.)


➡ When call forwarding is active, a special dial tone sounds when you lift the handset.

If DID DTMF is active (consult your administrator), you can also forward calls to this destination.

Destinations: Fax = 870, DID = 871, Fax-DID = 872.

If you are a call forwarding destination, your display will show the number or the name of the originator on the upper line and that of the caller on the lower line.

➡ Special features must be taken into consideration if your telephone operates with system networking via LAN → Page 101!

Prerequisite: The  key is not reprogrammed.

Press the key shown.

Open the idle menu → Page 16.

Select and confirm the option shown.

Confirm the option shown.

Select and confirm the option shown.

Select and confirm the option shown.

Enter the destination number.

Confirm the option shown.


The call forwarding symbol as well as the phone number and possibly also the forwarding destination name are displayed.

Deactivating call forwarding

Press the key shown.

Open the idle menu → Page 16.

Select and confirm the option shown.



Forwarding on?

1=all calls?

2=external calls only?

3=internal calls only?

Save?

100168

Forwarding off

Using call forwarding no reply (CFNR)

Calls that are not answered after three rings (=default, can be adjusted by administrator) or that are received while another call is ongoing can be automatically forwarded to a specified telephone.

Open the menu → Page 19.

Select and confirm the option shown.

Select and confirm the option shown.

Enter the destination number.

- Enter the internal station number for internal destinations
- Enter the external code and the external station number for external destinations

Confirm the option shown.

Deactivating call forwarding no reply

Open the menu → Page 19.

Select and confirm the option shown.

Select and confirm the option shown.

Confirm the option shown.

Select and confirm to return to idle mode and not deactivate call forwarding.



If CFNR is activated, "CFNR on" appears briefly on the display after you hang up.

The screenshot shows a vertical sequence of menu screens. The first section shows the activation process: a menu icon, a 'Program/Service?' dropdown, a '*495=CFNR on?' screen with a numeric keypad icon, a 'Save?' screen, and another menu icon. The second section shows the deactivation process: a menu icon, a 'Program/Service?' dropdown, a '#495=CFNR off?' screen, a 'Delete?' screen, and an 'or' separator. The final screen shows an 'Exit' option.

Call forwarding in the event of telephone failure (CFSS)

If configured (consult your administrator), you can define an internal or external call forwarding destination that activates in the event of telephone failure.

Open the menu → Page 19.

Select and confirm the option shown.

Select and confirm the option shown.

Enter the destination number.

Confirm the option shown.

Deactivating call forwarding/deleting a destination:

Open the menu → Page 19.

Select and confirm the option shown.

Select and confirm the option shown.

Confirm to deactivate and delete the forwarding destination.

Select and confirm to return to idle mode and not deactivate call forwarding.

Changing the forwarding destination (if call forwarding is active):

Open the menu → Page 19.

Select and confirm the option shown.

Enter the code.

Confirm the option shown.

Change the destination phone number.

Confirm the option shown.

Program/Service?

*9411= CFSS on?

Save?

Program/Service?

#9411= CFSS off?

Delete?

or

Exit?

Program/Service?

* 9 4 1 1

Change?

Save?

Call forwarding in the carrier network and forwarding multiple subscriber numbers (MSN) (not for U.S.)

If this function has been configured (consult your administrator), you can forward calls to your assigned multiple subscriber number MSN (DID number) directly within the carrier network.

For example, you can forward your phone line to your home phone after business hours.

Open the menu → Page 19.

Select and confirm the option shown.

Select and confirm the option shown.

Select and confirm the required type of call forwarding.

Select and confirm the option shown.

Select and confirm the option shown.

Enter your DID number.

Enter the destination number (without the external code).


Confirm the option shown.

Deactivating call forwarding

Select and confirm the option shown.

Confirm the displayed call forwarding type.

Enter your DID number.



The screenshot shows a vertical menu with several options. At the top is a small icon of a hand pointing to a grid. Below it is a dropdown menu labeled 'Program/Service?'. This is followed by a button labeled 'Trunk FWD on?'. Below that is a button labeled '1=immediate?'. To the right of this button is the word 'or'. Below that is a button labeled '2=on no answer?'. To the right of this button is the word 'or'. Below that is a button labeled '3= on busy?'. To the right of this button is a small icon of a hand pointing to a grid. Below that is a button labeled 'Save?'. Below that is a button labeled 'Trunk FWD off?'. Below that is a button labeled 'Confirm the displayed call forwarding type.'. At the bottom is a small icon of a hand pointing to a grid.

Using callback

You can request a callback if the internal station called is busy or if nobody answers. This also applies for external calls via ISDN exchanges. This feature saves you from having to make repeated attempts to reach the user.

You receive a callback:

- When the other party is no longer busy
- When the user who did not answer has conducted another call



When configured (consult your administrator), all callback requests are automatically deleted overnight.

Saving a callback

Prerequisite: You have reached a busy line or no one answers.

Confirm the option shown.

Accepting a callback

Prerequisite: A callback was saved. Your telephone rings and the following message appears on the display "Callback: ...".

Lift the handset.



or



or

Press the key shown. The LED lights up.

Select and confirm the option shown.

You hear a ring tone¹.

Callback?

Answer?

1. Pay attention to the notes on voice encryption → Page 63.

Viewing and deleting a saved callback

Open the idle menu → Page 16.

Select and confirm the option shown¹.

Select and confirm to display additional entries.

Deleting a displayed entry


Confirm the option shown.

Ending retrieval

Select and confirm the option shown.

Press the key shown. The LED goes out.

Press the key shown. The LED goes out.



1. "Differing display views in a HiPath 4000 environment" → Page 113

Enhanced phone functions

Accepting calls

Picking up a specific call for your colleague

You hear another telephone ring.

Open the menu → Page 19.

Select and confirm the option shown.

Select and confirm the option shown.

Select and confirm the option shown¹.

Select and confirm until the required station is displayed.

Confirm the option shown.

If you know the number of the telephone that is ringing, enter it directly².

Accepting calls via the headset

Prerequisite: The headset is connected.

The LED flashes when a call is received. Press the key shown. Conduct call.

Ending the call:

Press the key shown. The key LED extinguishes².

 Make sure your headset port is set up properly → Page 109.

1. "Differing display views in a HiPath 4000 environment" → Page 113
 2. Pay attention to the notes on voice encryption → Page 63.

Using the speakerphone

A colleague addresses you directly over the speaker with a speaker call. You hear a tone before the announcement. The other party's name or station number appears on the screen. You can conduct the call with the handset or in speakerphone mode.

Lift the handset and answer the call.

Press the "OK" key to confirm your selection and answer the call.



If handsfree answerback is enabled (see below), you do not need to switch on the microphone - you can answer directly. You can answer immediately in speakerphone mode.

If handsfree answerback is disabled (default setting), follow the procedure described above. Placing a speaker call to a colleague → Page 43.

Enabling and disabling handsfree answerback

Open the idle menu → Page 16.

Select and confirm the option shown.

Select and confirm the option shown.

Accepting calls from the entrance telephone and opening the door

If an entrance telephone has been programmed, you can use your telephone to speak to someone at the entrance telephone and to activate a door opener. If you have the proper authorization (consult your administrator), you can activate the **door opener**, enabling visitors to open the door themselves by entering a 5-digit code (e.g. using a DTMF transmitter or the keypad installed).


Speaking to visitors via the entrance telephone

Prerequisite: Your telephone rings.

Lift the handset within thirty seconds. You are connected to the entrance telephone immediately.

Lift the handset after more than thirty seconds.

Dial the entrance telephone number.



Open door?

Program/Service?

*61=Open door?

Program/Service?

*89=Door opener on?

3=change password?

1=enable with ring?

2=enable without ring?

Program/Service?

#89=Door opener off?

Opening the door from your telephone during a call from the entrance telephone

Confirm the option shown.

Opening the door from your telephone without calling the entrance telephone

Open the menu → Page 19.

Select and confirm the option shown.

Select and confirm the option shown.

Dial the entrance telephone number.



Special features must be taken into consideration if your telephone operates with system networking via LAN → Page 104!

Opening the door with a code (at the door)

After ringing the bell, enter the five-digit code (using the keypad or a DTMF transmitter). Depending on how the door opener has been programmed, a doorbell call signal may or may not be forwarded.

Activating the door opener

Open the menu → Page 19.

Select and confirm the option shown.

Select and confirm the option shown.

Dial the entrance telephone number.

Enter the five-digit code. Default code = "00000".

Select the displayed function and press "OK" to change the code.

Select and confirm the option shown.

You can also open the door without a doorbell ring.

Deactivating the door opener

Open the menu → Page 19.

Select and confirm the option shown.

Select and confirm the option shown.

Making calls

En-bloc sending/correcting numbers

If this feature is configured (consult your administrator), a connection is not attempted immediately when a station number is entered. This means that you can correct the number if necessary.

The station number is only dialed at your specific request.

Internal calls: Enter the phone number.

External calls: Enter the external code and the phone number.

Dialing entered/displayed numbers

Lift the handset.

Confirm the option shown¹.

Correcting numbers entered



A station number can only be corrected as it is being entered. Station numbers stored for number redial, for example, cannot be corrected.

Select and confirm the option shown.

The last digit entered in each case is deleted.

Enter the required digit(s).

Canceling en-bloc sending

Select and confirm the option shown.

Press the key shown. The LED goes out.



or

Call?

Delete number?



Cancel?

or



1. Pay attention to the notes on voice encryption → Page 63.

Using the caller list

Detailed information as well as a sample display entry are provided on → Page 18.

Retrieving the caller list

Prerequisite: Your administrator has set up a caller list for your telephone.
Open the idle menu → Page 16.
Confirm the option shown¹.

Press the illuminated key to open the call list.

The latest entry is displayed, see the example on → Page 18.

To view other calls, confirm each subsequent display.

Ending retrieval

Select and confirm the option shown.

Press the key shown. The LED goes out.

Press the key shown. The LED goes out.

Displaying the call time

Prerequisite: You have retrieved the caller list and the selected call is displayed → Page 18.

Select and confirm the option shown.

Dialing a station number from the caller list


Prerequisite: You have retrieved the caller list and the selected call is displayed.
Select and confirm the option shown².



The caller is automatically deleted from the caller list when a connection is finally set up.

Removing an entry from the caller list

Prerequisite: You have retrieved the caller list and the selected call is displayed.
Confirm the option shown.



1. "Differing display views in a HiPath 4000 environment" → Page 113
2. Pay attention to the notes on voice encryption → Page 63.

Calling a subscriber from the personal phonebook

Open the menu → Page 19.

Select and confirm to open the local phonebook.

Select and confirm the relevant entry. The connection is set up (see also → Page 82).

Calling a subscriber from the corporate directory

Prerequisite: You have searched for and selected a subscriber in the corporate directory → Page 85.

Confirm the subscriber. The connection is set up.

Calling a subscriber from the internal system phonebook

The internal system phonebook of your communication system contains all station numbers and system speed-dial numbers assigned to a name. Consult your administrator to find out if one was configured for your system.

Prerequisite: Names have been assigned to the station numbers stored in the system.

Lift the handset.

Press the key shown. The LED lights up.

Confirm the option shown.

If several phonebooks have been configured:

Confirm the option shown.

The first entry is displayed on the screen.

Scroll to next or previous entry.


Select and confirm the option shown.

Select and confirm the option shown.

Enter the name you want to find, or just the first few letters, using the keypad → Page 16.

Select and confirm each letter to be deleted. The last letter entered is deleted. If all letters are deleted, the first entry in the phonebook will be displayed again.

Select and confirm the option shown. All entered letters are deleted and the first entry in the phonebook is displayed again.





The entry you wish to dial appears on the screen

Select and confirm the option shown¹.

Using the LDAP directory from the system phonebook

If configured (consult your administrator), you can search for directory data in the LDAP database via the system phonebook of the communication system and dial the number of any subscriber you find there.

Prerequisite: The LDAP search feature has been configured in the system.

Lift the handset.



or




Press the key shown. The LED lights up.

Confirm the option shown.

if nec.

If several phonebooks have been configured in the system:



Select and confirm the option shown.




Enter the name you wish to search for using the keypad (max. 16 characters) → Page 16.

Partial entries are accepted, for example "Mei" for Meier.

if nec.

If configured (consult your administrator), you can also search for last name and first name. To separate last name and first name by a space, enter "0". Partial entries are accepted, for example "Mei P" for "Meier Peter".

if nec.



Select and confirm each letter to be deleted. The last letter entered is deleted.



In large databases, the results of the search may be incomplete if too few characters are entered → Page 41.



Confirm the option shown.

The name is searched for. This may take a few seconds.

1. Pay attention to the notes on voice encryption → Page 63.

Call?

 or

or

 Scroll Next?

or

 Scroll Previous?

 Call?

 Modify search?

 Show matches?

or

 Modify search?

The result is displayed

If only one name is found, it is displayed.

Confirm the option shown.

If several names are found (max. 50), the first name is displayed.

Scroll to the next or previous entry.

Confirm the option shown.

Select and confirm the option shown.

Select and confirm the option shown¹.

If no name is found

If your search does not yield any name corresponding to your query, you can extend the range of the search, for example by deleting characters.

Select and confirm the option shown.

For further procedure, see above.

If too many names are found

If more than the maximum of 50 names are found corresponding to your query, only an incomplete list of results can be displayed.

You can view these results, select any of the names or change the search (e.g. narrow the search by entering more characters).



In this case it is advisable to narrow down the search so that all corresponding names can be displayed.

Confirm to view the incomplete list.

For further procedure, see above.

Narrow down the search.

Select and confirm in order to change the search.

For further procedure, see above.

1. Pay attention to the notes on voice encryption → Page 63.

Making calls using system speed-dial numbers

Prerequisite: You know the system speed-dial numbers (consult your administrator).

Open the menu → Page 19.

Select and confirm the option shown.

Select and confirm the option shown¹.

Enter a three-digit speed-dial number².

Suffix dialing

If necessary, you can suffix-dial additional digits (for example, the user's extension) at the end of the saved station number.

If this feature is configured, a suffix is automatically dialed (for example, "0" for the exchange) if no entries are made within 4 or 5 seconds.

Dialing with speed-dial keys

Prerequisite: You have configured speed-dial keys → Page 42.

Open the menu → Page 19.

Select and confirm the option shown.

Select and confirm the option shown^[1].

Press the key shown.

Press the required speed-dial key².

Configuring a speed-dial key

You can program the keys  to  with ten frequently used phone numbers.

Open the menu → Page 19.

Select and confirm the option shown.

Select and confirm the option shown^[1].

Confirm the option shown.

Press the key shown.

Press the required speed-dial key. If the key is already in use, the programmed phone number appears on the screen.


Confirm the option shown.

First enter the external code and then the external station number.

Confirm the option shown.

1. "Differing display views in a HiPath 4000 environment" → Page 113

2. Pay attention to the notes on voice encryption → Page 63.



or

Previous?

Next?

or

Change?

or


Delete?

or

Exit?

▼

*80=Speaker call?



If you make a mistake:

Select and confirm the option shown. This deletes all numbers entered.

Confirm the option shown.

Select and confirm the option shown.

Select and confirm the option shown.

Select and confirm the option shown.


Talking to your colleague with a speaker call

You can make a speaker announcement through a loudspeaker if connected (consult your administrator) or to an internal user with a system telephone without any action on their part.

Open the idle menu → Page 16.

Select and confirm the option shown.

Enter the phone number.

 Responding to a speaker call → Page 35.

Talking to your colleague with discreet calling

If this function has been configured (consult your administrator), you can join an ongoing call conducted by an internal user on a system telephone with display. You can listen in unnoticed and speak to the internal user without being overheard by the other party (discreet calling).

Lift the handset.

Enter the code.

Enter your internal station number.



Your administrator can protect your telephone against discreet calling.

Automatic connection setup (hotline)

If this function is configured (consult your administrator), the system automatically sets up a connection to a preset internal or external destination.

Lift the handset.

Depending on the setting, the connection is either set up **immediately** or only **after** a preset **period of time** (= hotline after a timeout).

Reserving a trunk

If configured (consult your administrator), you can reserve an occupied line for yourself. When the line is free, you receive a call and a note on the display.

Prerequisite: "Currently busy" appears on the display.


Confirm the option shown.

Reserved line is free:

Your telephone rings. "Trunk is free" appears on the display.

Lift the handset. You will hear the dial tone.

Enter the external phone number.



Reserve trunk



Assigning a station number (not for U.S.)

If this function has been configured (consult your administrator), you can selectively assign a specific number (DID number) to your telephone before making an external call. The assigned number then appears on the called party's display.

Open the menu → Page 19.

Select and confirm the option shown.

Select and confirm the option shown.

Enter the DID number you wish to use.

Dial the external number.

Associated dialing/dialing aid

If this function has been configured (consult your administrator), you can use a dialing aid to dial numbers and set up calls for your telephone.

The operating procedure depends on whether the dialing aid is connected to the **S₀ bus** or the **a/b (T/R) port**.

You can also use your system telephone as a dialing aid for other telephones.

Dialing aid on the S0 bus

On the PC, select a destination and start dialing.

The speaker on your telephone is switched on. Lift the handset when the other party answers.

Dialing aid at the a/b (T/R) port

On the PC, select a destination and start dialing.

"Lift the handset" appears on the PC screen.

Lift the handset.

Dialing aid from your telephone for another telephone:


Open the menu → Page 19.

Select and confirm the option shown.

Select and confirm the option shown.

Enter the internal station number ("Call for:").

Enter the number you wish to dial.



During a call

Using call waiting (second call)

Callers can still reach you while you are conducting another call. A signal alerts you to the waiting call.

You can ignore or accept the second call.

When you accept the waiting call, you can either end the first call or place it on hold and resume the call later on.

You can also block the second call or the signal tone → Page 47.

Prerequisite: You are conducting a phone call and hear a tone (approx. every six seconds).

Ending the first call and answering the waiting call

Replace the handset. Your phone rings¹.

Answer the second call. Lift the handset.

Placing the first call on hold and answering the second call

Select and confirm the option shown¹.

You are connected to the second caller. The first party is placed on hold.

Ending the second call and resuming the first one

Confirm the option shown.

Replace the handset.

Recall the first party.

Lift the handset.

Call waiting?

Quit and return?

or

↶ • 23189 Coco

1. Pay attention to the notes on voice encryption → Page 63.

Preventing and allowing call waiting (automatic camp-on)

If this function has been configured (consult your administrator), you can prevent or allow a second call → Page 46 from being signaled by automatic camp-on during an ongoing call.

Open the menu → Page 19.

Select and confirm the option shown.

Select and confirm the option shown¹.

Select and confirm the option shown.

Turning the call waiting tone on and off

You can suppress the call waiting tone (approx. every six seconds) for second calls. A single special dial tone then alerts you to the waiting call.

Activating

Open the idle menu → Page 16.

Select and confirm the option shown.

Deactivating

Open the idle menu → Page 16.

Select and confirm the option shown.

Saving a number

You can save your call partner's station number for subsequent redialing from the caller list → Page 38.

Prerequisite: You are conducting a call.

Select and confirm the option shown.

The screenshot shows a vertical menu on a light gray background. At the top, there is a small icon of a phone with a speech bubble. Below it is a dropdown menu labeled "Program/Service?". Underneath is a text field containing "#490=Call wait.trm.off?". To the right of this field is the word "or". Below "or" is another text field containing "*490=Call wait.trm.on?". Further down, there is a dropdown menu with a downward arrow icon, followed by a text field labeled "Waiting tone off?". Below this is another dropdown menu with a downward arrow icon, followed by a text field labeled "Waiting tone on?". At the bottom of the menu is a text field labeled "Save number?".

1. "Differing display views in a HiPath 4000 environment" → Page 113

Parking a call

You can park up to ten internal and/or external calls. Parked calls can be displayed and picked up on another telephone. This feature is useful, for example, if you want to continue a call at another phone.

Prerequisite: You are conducting a call.

Open the menu → Page 19.

Select and confirm the option shown.

Select and confirm the option shown.

Enter the number of the park position (0 - 9) and make a note of it. If the park position number you entered is not displayed, it is already in use; enter another one.

Retrieving a parked call

Prerequisite: One or more calls have been parked. The phone is idle.

Open the menu → Page 19.

Select and confirm the option shown.

Select and confirm the option shown¹.

Enter the park position number you noted earlier.

If the park position number you enter is not in use, you cannot retrieve the call.



If a parked call is not picked up, after a specific period of time the call is returned to the telephone from where it was parked (recall).

The image shows two screenshots of a telephone interface. The top screenshot shows the 'Park a call' menu with the option '*56=Park a call?' selected. The bottom screenshot shows the 'Retrieve call?' menu with the option 'Retrieve call?' selected. Both screenshots show a 'Program/Service?' dropdown menu and a 'wxyz' button.

1. "Differing display views in a HiPath 4000 environment" → Page 113

Holding external calls

If you have programmed a hold key on your phone → Page 55, you can put external calls on hold.

All other stations can then pick up the call on the assigned line.

Press the key shown.

The message of the relevant trunk appears (e.g. 801); note the trunk number. If available, the LED of the assigned trunk key flashes slowly.

Replace the handset or press the key shown.

Depending on the configuration, this may be necessary so other members can also pick up the call on hold.

Picking up a call on hold

Prerequisite: One or more calls are on hold. The phone is idle.

Open the menu → Page 19.


Select and confirm the option shown.

Select and confirm the option shown.

If the "Retrieve" key → Page 55 is available, press it.

Enter the noted trunk number.

If there is a "Line:" key available for the relevant trunk, the LED flashes slowly. Press the key shown.



Conducting a conference

In a conference call, you can talk to as many as four other parties at the same time. These may be internal or external users.



You can only add parties to or remove them from a conference if you initiated the conference.

Call the first party.

Select and confirm the option shown.

Call the second party. Announce the conference.

Select and confirm the option shown.

Press the key shown.

A tone sounds every 30 seconds to indicate that a conference is in progress (can be disabled, consult your administrator).



If voice encryption is not activated or not available on a conference party's phone, the entire conference is not secure. It may be indicated that the call is not secure → Page 63.

If the second party does not answer

Confirm the option shown.


Adding up to five parties to a conference

Confirm the option shown.

Call the new party. Announce the conference.

Select and confirm the option shown.

Press the key shown.



View conf parties?

Next?

Remove party?

Leave conference?

or



End conference?

or



Drop last conf. party?



Program/Service?

*53=DTMF dialing?



Removing parties from the conference

Select and confirm the option shown. The first party is displayed.

Confirm as often as required until the desired party appears.

Select and confirm the option shown.



If a participant who was connected to the conference via an unencrypted line leaves, the conference remains unsecured.

Leaving a conference

Select and confirm the option shown.

Replace the handset if this feature is configured (consult your administrator).

Ending a conference

Select and confirm the option shown.

Replace the handset if this feature is configured (consult your administrator).

Removing the central office party from the conference

Select and confirm the option shown.

Activating tone dialing/DTMF suffix dialing

You can transmit **dual-tone multifrequency** (DTMF) signals to control devices such as an answering machine or automatic information system.

Open the menu → Page 19.

Select and confirm the option shown.

Select and confirm the option shown.

You can use the keys through , and to transmit DTMF signals.



Ending the call also deactivates DTMF suffix dialing.
Your system may be configured so that you can start DTMF suffix dialing immediately after setting up a connection.


Recording a call

If configured (consult your administrator for details), you can record an active call.

Prerequisite: You are on a call, the "Recording" key is configured → Page 55.

Press the "Recording" key. The LED lights up.

You and the other party hear an announcement that recording has started and as long as recording is still running, you hear an acoustic signal approx. every 15 seconds.

 During recording, it is not possible to add further call parties.

Stopping recording

Press the illuminated "Recording" key. The LED goes out.

Listening to a recording

Playback of the recording depends on the voice recording system used (see the relevant user manual).

Transferring a call after a speaker call announcement in a group

If this function has been configured (consult your administrator), you can use a speaker call (announcement → Page 43) to announce a call in progress to a group of users → Page 95.

Once a member of the group has accepted the call request, you can transfer the waiting party.

Prerequisite: You are conducting a call.

Confirm the option shown. The other party is placed on hold.

Press the key shown.

Select and confirm the option shown.


Enter the group's station number.

Announce the call.

When a member of the group answers the call → Page 35, you are connected to this party.

Replace the handset.

Select and confirm the option shown¹.

 If the connection between the two other parties is not established within 45 seconds, the call from the first party returns to you (=recall).

Consultation?



*80=Speaker call?



or

Transfer?

1. "Differing display views in a HiPath 4000 environment" → Page 113

Sending a trunk flash

To activate ISDN-type services and features through the network carrier's analog trunks or those of other communication platforms (such as "consultation hold"), you must send a signal to the trunks before dialing the service code or telephone number.

Prerequisite: You have set up an external connection.

Open the menu → Page 19.

Select and confirm the option shown.

Select and confirm the option shown.

Enter the service code and/or telephone number.

If you cannot reach a destination

Call waiting (camp-on)

Prerequisite: You have dialed an internal number and hear a busy signal. It is important that you reach the called party.

Wait (approx. 5 seconds) until "Camp-on" appears on the display and the busy tone is followed by the ring tone.

The called party can then respond → Page 46.



The called party can prevent this automatic call waiting → Page 47.

If this feature is configured (consult your administrator), you will hear the ring tone and the message "Camp-on" is immediately displayed.

Busy override - joining a call in progress

This function is only available if it has been configured (consult your administrator).

Prerequisite: You have dialed an internal number and hear a busy signal. It is important that you reach the called party.

Select and confirm the option shown.

The called party and person to whom this party is talking hear an alerting tone every two seconds.

If the called party has a system telephone with display, the following appears on the screen: "Override: (Number or name)".

You can now start talking.

Program/Service?

*51=Trunk flash?

Camp-on

Override?

Using night answer

When night answer mode is active, for example during a lunch break or after office hours, all external calls are immediately forwarded to a specific internal telephone (night station). The night station can be defined by your administrator (= standard night answer service) or by you (= temporary night answer service).



Special features must be taken into consideration if your telephone operates with system networking via LAN → Page 102!

Activating

Select and confirm the option shown.

Press the "OK" dialog key to confirm (= standard night answer service).

Enter the code (= standard night answer service).

Enter the destination number (= temporary night answer service).

Confirm the option shown.

Deactivating

Select and confirm the option shown.

The administrator can also configure an "automatic night answer service". The automatic night answer service activates at specific times for your telephone depending on how it is programmed.

You can deactivate the automatic night answer service or replace it with a night answer service you configured (see above).

Night answer on?

*=default?

or



or



Save?


Night answer off?

Programming the function keys

You can program frequently used functions, station numbers or procedures onto the function keys on your OpenScape Desk Phone IP 35 G or key module.

Configuring function keys

Please see also the information on → Page 15.

 A list of all available functions is displayed, see the overview → Page 56.

Example: Programming the Shift key

Open the menu → Page 19.

Select and confirm the option shown.

Select and confirm the option shown.

Press the key shown.

Confirm the option shown.

Select and confirm the option shown.

Confirm the option shown.

Select and confirm the option shown.


Some functions (e.g. with "Call forwarding") can be saved even if they are incomplete. This means that when later initiating the function by pressing the button, further inputs are required.

Confirm the option shown.

Select and confirm the option shown.

The label appears automatically and cannot be changed for the Shift key. It can be changed for all other functions.

The LED displays show the status of the function → Page 15 and → Page 56.



The screenshot shows a vertical menu on a light gray background. At the top right is a small icon of a document with a pencil. The menu items are as follows:

- Program/Service? (with a downward arrow icon)
- *91=Prog. feature key (with a black rectangular button icon to its right)
- Change key
- More features (with a rightward arrow icon)
- Shift key (with the text "if nec." to its right)
- Save incomplete
- Exit (with the text "or" to its right)
- Another key

Overview of functions

The functions are split into the following menus:

- Destinations
- Control Relay
- PIN and Authorization
- Calls
- More Features



The available functions depend on your configuration. If a function is missing, consult your administrator.

Saved function LED messages

Call forwarding, Forwarding - trunk, Forward line, Night answer, Do not disturb, Telephone lock, Advisory message, Ringer cutoff, HF answerback on/off, Join/leave group, Caller ID suppression, Call wait.trm., Waiting tone off, Ring transfer, Recording, Door opener on/off, Control relay (only for HiPath 3000), Ringing group on, Shift key, UCD (Available on/off, Work on/off), Night answer on/off, MULAP privacy release:



Saved function is not activated.



Saved function is activated.

Callback:



You have no entry for callback.



You have an entry for callback.

Redial key (internal), direct station select:



Party not on a call.



Party is on a call or has activated DND.



Flashing quickly - I'm being called, please accept.

Flashing slowly - another party is being called and has not yet accepted the call.

Call key, General call key, Trunk key, MULAP key, Temporary MSN:



No call via the corresponding trunk.



Active call via the corresponding trunk.



Flashing quickly - call on the corresponding trunk, call pickup is possible by pressing the key.

Flashing slowly - a call is placed on hold on the relevant trunk.

Trunk group key:

At least one trunk is free.



All lines in this trunk group are occupied.

View call charges:

No chargeable calls have been set up since the last check.



Chargeable calls have been set up since the last check.

Call forwarding, Forward line:

Flashing slowly - your line is a call forwarding destination.

Fax/answering machine details:

No fax received or no message on the answering machine.



Fax received or message on the answering machine.

View the number of calls:

No waiting callers.



Flashing quickly - callers waiting (certain number is exceeded).

Flashing slowly - callers waiting (certain number is reached).

Data I/O service:

No connection to an application.



Active connection to an application.



Flashing slowly - connection to an application is temporarily interrupted.

The following functions programmed on keys do not have a LED function:

Redial key (external), Procedure key, Trace call, Speed dial, Clear, Lock all phones, Send message, Directory (1=internal, 2=LDAP), Call waiting, Toggle/Connect, Conference, Speaker call, Retrieve line, Reserve trunk, Release trunk, Temporary phone, Override, Park a call, Pickup - directed, Pickup - group, Account code, Show call charges, Page, Answer page, Timed reminder, Open door, DTMF dialing, Recall key, Room monitor, Hold key, Consult internal, Consultation, Associated dial, Associated serv., Tel. data service, Mobile login, Discreet call.

Programming a procedure key

Numbers and functions that require further input, i.e. which contain several operating steps, can be saved on a key on your telephone. The relevant administrator must have granted the appropriate authorization.

For example the function "Associated dialing" → Page 45 together with the required input (phone number of the phone for which the call is to be made + phone number to be dialed) can be saved on a key. Numbers that require further input can also be saved.

Please see also the information on → Page 15.

Open the menu → Page 19.

Select and confirm the option shown.

Select and confirm the option shown.

Press the key shown.

Confirm the option shown.

Select and confirm the option shown.

Select and confirm the option shown.

Enter procedure. Example: ***67 231 123456**

Code for associated dialing

Number of the phone for which the call should be made

The number to be dialed.

Press the "Pause" key to enter pauses (a "P" appears on the display).

Confirm the option shown.

If you make a mistake:

Select and confirm the option shown. This deletes all numbers entered.

Confirm the option shown.


Select and confirm the option shown.



Select the saved procedure by pressing the key.

Procedures with activatable/deactivatable functions are activated by pressing the key once and deactivated by pressing it again.

You can press the procedure key during a call to automatically send the saved digits as DTMF signals → Page 51. For display messages when saving procedures, see → Page 117.



Configuring repdial keys

You can also program internal and external station numbers at the second level. The LED function is not available for internal station numbers at the second level. A "Shift" key → Page 55 has to be configured in order to program the second level.

Please see also the information on → Page 15.

Open the menu → Page 19.

Select and confirm the option shown.

Select and confirm the option shown.

Press the key shown.

Confirm the option shown.

Select and confirm the option shown.

Confirm the option shown.

Confirm the option shown.

Enter the phone number.

If you make a mistake:

Select and confirm the option shown. This deletes all numbers entered.

Confirm the option shown.

Select and confirm the option shown.



You dial the saved number by pressing the key → Page 26.

You can also save a number during a call.

Deleting function key programming

Open the menu → Page 19.

Select and confirm the option shown.

Select and confirm the option shown.

Press the key shown.

Select and confirm the option shown.

The screenshot shows a vertical menu on a device screen. At the top is a 'Program/Service?' dropdown menu. Below it is a field containing '*91=Prog. feature key'. A black square icon is visible below this field. The next option is 'Change key', followed by 'if nec.' and '+=Next level'. Below that is 'Destinations' with a right-pointing arrow. The next option is 'Repdial key', followed by a keypad icon. Below the keypad icon are 'Previous' and 'Exit' options. An 'or' label is positioned between 'Exit' and 'Another key'. At the bottom of the menu is a 'Clear key' option. A small icon with three horizontal lines is visible at the very top of the menu area.

Displaying and assigning call charges

Displaying call charges (not for U.S.)

For the current call:

Call charges are shown by default on the display when a call ends.

If you want to display call charges as they occur during a chargeable call, your administrator must request this option from the network operator.

Call charge display must be requested from the network operator and configured by the relevant administrator.

Depending on the setting, call charges are displayed during or after a call.

Depending on the network operator, free external calls are also displayed.

The message "Free of Charge" appears on the screen either before or during the call.

If the cost indication facility has not been installed, the display will show the dialed number and/or the duration of the telephone call.



If a call is forwarded, call charges are assigned to the destination of the call transfer operation.

For all calls and for the last call

Connection charges for the last chargeable call made are displayed first.

After five seconds, the accumulated connection charge (total) is displayed.

Open the menu → Page 19.

Select and confirm the option shown.

Select and confirm the option shown¹.

Displaying call charges for another telephone (not for U.S.)

If configured (consult your administrator), you can also display and print information on chargeable calls for other phones (such as a pay phone).

Prerequisite: You have programmed the function "Show call charges" on a key → Page 55.

The LED lights up to indicate that you have conducted a chargeable call since the last time you viewed the charges.

Press the "Call Charges" key. Chargeable calls are displayed.

Press to display further chargeable calls.

Select and confirm the option shown.

Select and confirm the option shown.

1. "Differing display views in a HiPath 4000 environment" → Page 113



Program/Service?

*65=Show call charges?

Next

Print

or

Delete

or

Add'l information

or

Exit

>≡

Program/Service?

*60=Account code?

if nec. #

or

#=Save?

Select and confirm the option shown.

Select and confirm the option shown.

Dialing with call charge assignment

You can assign external calls to certain projects.

Prerequisite: Your administrator has defined account codes for you.

Open the menu → Page 19.

Select and confirm the option shown.

Select and confirm the option shown.

Enter the account code.

Press this key.

Confirm the option shown.

Required depending on the configuration; consult your administrator.


Enter the external phone number.



You can also enter the account code during an external call.

Privacy/security

Voice encryption

 Please see also the explanations on → Page 11.

Displaying status

in call mode

During calls, you can check if your call is secure.

If a key is configured with the "Security call status" function, this illuminates if the call is secure.

Select and confirm the option shown.

Press the "Security call status" key (if configured).

The call is secure.

The call is not secure.

in idle status

You can see whether voice encryption is active on your phone from the display when the phone is in idle mode.

Open the idle menu → Page 16.

Select and confirm the option shown.

Voice encryption is activated for your telephone.

Voice encryption is not activated for your telephone.

5170 ▲

or



1086

or

1087



Security status ▲

Secure client

or

Standard client

Notes on voice encryption

Your administrator can define in the communication system whether and how you are notified of unencrypted calls. You will then receive a warning tone and/or a message on the display when you accept a call, accept a consultation call or are connected to a conference.

Warning tone

Display for an unencrypted call.

Display for an encrypted call.

Turning ringer cutoff on and off

If you do not wish to take calls, you can activate the ringer cutoff function. Calls are only identified by **one** ring signal and they are shown on the display.

Activating

Open the idle menu → Page 16.

Select and confirm the option shown¹.

Deactivating

Open the idle menu → Page 16.

Select and confirm the option shown.

The screenshot shows a vertical menu on a light gray background. At the top, there is a musical note icon and the text "and/or". Below this is a rectangular button labeled "Standard call". Further down, there is the text "or" followed by another rectangular button labeled "Secure call". At the bottom of the menu, there are two more options, each preceded by a small square icon containing a downward-pointing chevron (▼). The first option is labeled "Ringer cutoff on?" and the second is labeled "Ringer cutoff off?".

1. "Differing display views in a HiPath 4000 environment" → Page 113

Activating/deactivating "Do not disturb"

If you do not wish to take calls, you can activate do not disturb. Internal callers hear the busy tone, external callers are connected to another phone, which you can specify (consult your administrator).

Activating

Open the idle menu → Page 16.

Select and confirm the option shown.

Deactivating

Open the idle menu → Page 16.

Confirm the option shown.



When you lift the handset, you will hear a special tone (continuous buzzing) reminding you that "Do not disturb" is activated.

Authorized internal callers automatically override the DND feature after five seconds.

Caller ID suppression

You can prevent your station number or name from appearing on the displays of external parties you call. The feature remains active until you deactivate it.

Activating

Open the idle menu → Page 16.

Select and confirm the option shown.

Deactivating

Open the idle menu → Page 16.

Select and confirm the option shown.



Your administrator can activate/deactivate caller ID suppression for all phones.



DND on?



DND off?



Suppress call ID?



Restore caller ID?

Monitoring a room

You can use a phone to monitor a room. This function must be enabled on the monitoring phone.

When you call this phone, you can immediately hear what is happening in that room.

Activating the telephone to be monitored

Open the menu → Page 19.

Select and confirm the option shown.

Select and confirm the option shown.

You can either leave the telephone in speakerphone mode or lift the handset and leave it directed towards the noise source.

Deactivating the telephone to be monitored

Press the illuminated key. The LED goes out.

Replace the handset.

Monitoring the room

Enter the internal station number of the phone located in the room that you wish to monitor.

Trace call – identifying anonymous callers (not for U.S.)

You can identify malicious external callers. You can record the caller's phone number during a call or for up to 30 seconds after a call. You should not hang up in the process.


Open the menu → Page 19.

Select and confirm the option shown.

Select and confirm the option shown.



If the trace is successful, the transmitted data is stored by your network operator. Consult your administrator.



Locking the telephone to prevent unauthorized use

You can prevent unauthorized parties from accessing certain functions on your phone during your absence, for example you can prevent external phone numbers being dialed or your mailbox being accessed. Consult your administrator to determine which functions are locked.

Locking the phone

Open the idle menu → Page 16.

Select and confirm the option shown.

Select and confirm the option shown.

Enter code (telephone lock) → Page 67.



When the phone is locked, a special dial tone sounds when the handset is lifted. Internally, users can make calls as normal.

Your phone can also be locked or unlocked by an authorized party → Page 66.

Unlocking the phone

Open the idle menu → Page 16.

Select and confirm the option shown.

Enter code (telephone lock) → Page 67.

Locking another telephone to prevent unauthorized use

If configured (consult your administrator), you can lock and unlock other telephones to prevent unauthorized access.

If a phone user locks his or her phone and forgets the PIN code, you can use this function to unlock the phone.

Open the menu → Page 19.

Select and confirm the option shown.

Select and confirm the option shown.

Enter the internal station number of the phone you wish to lock/unlock.

Confirm the option shown.

Select and confirm the option shown.

The screenshot shows a vertical menu interface on a light gray background. At the top, there is a dropdown arrow icon. Below it is a text box labeled "Lock phone?". To the right of this box is the word "or". Below "or" is another text box labeled "Unlock phone?". To the right of this box is a small icon of a keypad with a hand cursor pointing at it. Further down, there is another dropdown arrow icon. Below it is a text box labeled "Unlock phone". To the right of this box is the same keypad icon. At the bottom, there is a menu icon (three horizontal lines). Below it is a dropdown menu labeled "Program/Service?". Below that is a text box labeled "*943=Lock all phones?". To the right of this box is the keypad icon. Below that is a text box labeled "*=lock phone?". To the right of this box is the word "or". At the very bottom is a text box labeled "#=unlock phone?".

Saving your PIN code

Enter a PIN code to use the functions

- for locking the telephone to prevent unauthorized use → Page 66
- for using another telephone like your own → Page 71

You can save this code.

Open the menu → Page 19.

Select and confirm the option shown.

Confirm the option shown.

Enter the current five-digit code.


If you have not yet set a code, use "00000" the first time.

Enter the new code.

Re-enter the new code.



If you forget your code, consult your administrator, who can reset your code to "00000".



More functions/services

Appointment reminder function

You can configure your phone to call you to remind you about appointments
→ Page 69.

You must save the required call times. You can enter a single appointment that will take place in the next twenty-four hours or you can enter a daily recurring appointment.

Saving a timed reminder

Open the menu → Page 19.

Select and confirm the option shown.

Confirm the option shown.

Enter a 4-digit time such as 0905 for 9.05 (= 9.05 a.m.) or 1430 for 14.30 (= 2.30 p.m.).

If the selected language is "US English" (Settings → Page 107) you can enter the code 2 for "am" or 7 for "pm" (default = "am").

Confirm the option shown.

Select and confirm the option shown.

Confirm the option shown.

Deleting and checking a saved appointment

Open the menu → Page 19.


Select and confirm the option shown.

Confirm the option shown.

Confirm the option shown.

Select and confirm the option shown.

The image shows a vertical sequence of menu screens from a mobile phone. The first screen has a menu icon at the top right, followed by a dropdown menu labeled 'Program/Service?'. Below that is a screen with the text '*46=Timed reminder on?' and a 4-digit time entry field. The next screen shows 'if nec.' followed by two options: '2abc' and '7pqrs'. This is followed by a screen with 'One time only?' and an 'or' separator, then a screen with 'Daily?'. The next screen is 'Save?'. Below this is another menu icon, followed by a dropdown menu labeled 'Program/Service?'. The next screen is '#46=Timed reminder off?'. This is followed by a screen with 'Delete?' and an 'or' separator, then a screen with 'Exit?'. The background is a light gray.



Using timed reminders

Prerequisite: You have saved a reminder → Page 68. The saved time arrives. The phone rings. The appointment time is displayed.

Press the key twice.

Lift the handset and replace it again.

➡ If you do not answer the timed reminder, it is repeated five times and then deleted.

Sending a message

You can send short text messages to individual stations or groups of stations with system telephones.

Creating and sending a message

Open the idle menu → Page 16.

Select and confirm the option shown.

Enter the internal station number of the recipient or group.

Select predefined text (can be changed by the administrator) and confirm.

Enter the code directly.

The code is shown on your display with the corresponding message.

Select and confirm the option shown.

Text entry (up to 24 characters) → Page 16.

Confirm the option shown.

➡ Transmitted text messages are saved as callback requests on system telephones with no display and on ISDN, pulse or tone dialing telephones.

Displaying and deleting messages you have sent

Prerequisite: The recipient has not yet accepted a sent message.

Open the idle menu → Page 16.

Select and confirm the option shown.

Confirm the option shown.

The text message is displayed.

Select and confirm the option shown.

The message is deleted.

Viewing and editing incoming messages

Pay attention to the notes on → Page 17.

The LED lights up. Press the key shown.

Confirm the option shown.

The sender's caller ID appears on the display.

Confirm the option shown.

The text message appears on the display.

Viewing the transmission time

Confirm the option shown.

Calling the sender

Select and confirm the option shown.

Deleting messages

Select and confirm the option shown.

Leaving an advisory message

You can leave messages/advisory messages on your phone's display for internal callers who wish to contact you in your absence.

When you receive a call, the message appears on the caller's display.

Open the idle menu → Page 16.

Select and confirm the option shown.

Select predefined text (can be changed by the administrator) and confirm.

Enter the code directly.

The code is shown on your display with the corresponding message.




Predefined messages with a colon can be completed by entering a digit.

Select and confirm the option shown.

Enter message (up to 24 characters) → Page 16.

Confirm the option shown.



Deleting advisory messages

Open the idle menu → Page 16.

Select and confirm the option shown.

Displaying the number of waiting calls/ overload display

You can show the number of external waiting calls on the display if you programmed a key with "View number of calls" → Page 55.

Press the "Calls in Q" key.

If the number of waiting calls exceeds a preset limit while you are conducting another call (overload), the LED on the key lights up.

- LED off: There are no waiting calls.
- LED is flashing slowly: The set limit has been reached.
- LED is flashing quickly: The limit has been exceeded (overload).

Using another telephone like your own for a call

Other parties can temporarily use your phone like their own for an outgoing call.

Open the menu → Page 19.

Select and confirm the option shown.

Select and confirm the option shown.

Select and confirm the option shown¹.

Enter the number of the other user.

Enter the other user's code → Page 67.

if nec.

If the other user has not set a PIN, he or she is prompted to do so on his or her phone.

Dial the external number.

This state is canceled as soon as the call is ended.

1. "Differing display views in a HiPath 4000 environment" → Page 113

Using a mobile connection at a random phone

You can program a mobile phone number that was set up especially for you by your administrator at a system-based OpenScape Desk Phone of your choice. The original "guest telephone" setting is deactivated. The mobile connection remains available until you log off from the "guest telephone".

Mobility variants

There are three Mobility variants available:

- Basic
- Data Privacy
- Data Mobility

The administrator is responsible for assigning the Mobility variant for the respective phone.

Basic

The following settings for the mobile connection are adopted after logging in to the guest telephone.

- Key assignment
- Class of service
- Call forwarding

Pending messages or information are signaled additionally (message waiting indicator or MWI).

You can see and use the guest telephone phonebook.

Data Privacy

The following settings for the mobile connection are adopted after logging in to the guest telephone.

- Key assignment
- Call forwarding
- Class of service (except for user password)

Pending messages or information are signaled additionally (message waiting indicator or MWI). The user password is not adopted, which means that you have to create a new password on the phone, for example, if you want to use OpenStage Manager. An empty phonebook is made available. You cannot see the guest telephone phonebook. You can use OpenStage Manager to also load your own personal phonebook if appropriate. Any data modified in the phonebook is lost by logging out. You should therefore make sure to save any modified data via OpenStage Manager before logging out.

Data Mobility

The following settings are adopted when you "move" to the guest telephone.

- Key assignment
- Call forwarding
- Class of service
- User password
- Phonebook

Pending messages or information are signaled additionally (message waiting indicator or MWI). The phonebook and user password are saved on a DLS server for both the home and guest telephones. This data is updated immediately when changes are made. The saved data for the home telephone is transferred from the DLS server to the guest telephone during the login process.

Logging on to the "guest telephone"

Log on to the "guest telephone" with a mobile connection.

Prerequisite: A mobile connection with a dedicated phone number and password have been set up for you (ask your administrator). The "Mobile Login" key may be configured on your OpenScope Desk Phone.

Press the "Mobile Login" key.

or

If no key is configured,

Enter the code for "Mobile Login (Log on)", (see → Page 126).
You see the prompt "New number".

Enter the mobile phone number.

You are prompted to enter the "Code for **nnn**" (e.g. 834):

if nec.

Enter the password and confirm.

or

Press the key shown.

or

Entry complete

Confirm the option shown.

The logon procedure begins.

Your mobile phone number will appear on the left of the display when you are correctly logged on → Page 16.

You can no longer see the original user settings for the "guest telephone" but you can now use your mobile connection. Entries are only temporarily saved in the call lists and personal phonebook, in other words they are no longer there the next time you log on.

Basic

You can no longer see the original user settings for the guest telephone, however you can now use your mobile connection with the exception of your personal phonebook.

Data Privacy

You can no longer see the original user settings for the guest telephone, however you can now use your connection and an empty phonebook.

Data Mobility

You can use your connection and your Mobility phonebook. If you make changes in the phonebook, these will be signaled immediately on the server.

Moving the connection to the next telephone

If you want to move your connection from the first "guest telephone" to a second "guest telephone", log on to the second "guest telephone" in the usual fashion (see → Page 73).

The message "Log off successful" is output on the first "guest telephone". The second "guest telephone" is now blocked. You can now use the second "guest telephone" in the same way as the first one.

Logging off from the "guest telephone"

If you no longer require your connection on the guest telephone, or if you want to change to a different telephone, then simply log out from the guest telephone. Save any current changes in the phonebook via OpenStage Manager.

Press the "Mobile Login" key.

or



If no key is configured,

Enter the code (e.g. #9419) for "Mobile Login (log out)" (See Overview of functions and codes (alphabetic)). The logout process starts.

The guest telephone can now be used again with its original phone number, features and functions. Any call forwarding that has been set up can be canceled again.



The data for the guest telephone is restored again via the DLS server in the case of the "Data Mobility Variant".

Fax details and message on answering machine

If a fax or answering machine is connected to your system and you have assigned the "Fax details" function to a programmable key → Page 55, the key lights up when a fax or a message has been received.

Deactivating signaling



Press the illuminated "Fax service" key. The LED goes out.

Resetting services and functions (system-wide cancelation for a telephone)

A general reset procedure is available for initiated functions. The following functions are deleted, if enabled:

- Forwarding on
- Advisory msg. on
- Ringing group on
- Hunt group off
- Suppress caller ID
- Waiting tone off
- DND on
- Ringer cutoff on
- Received messages
- View callbacks

Open the menu → Page 19.

Select and confirm the option shown.

Select and confirm the option shown¹.

Activating functions for another telephone

If configured (consult your administrator), you can activate and deactivate the following functions for other phones (associated service):

- Do not disturb, code *97/#97 → Page 64
- Call forwarding, code *11, *12, *13/#1 → Page 28
- Lock and unlock phone, code *66/#66 → Page 66
- Ringing group, code *81/#81 → Page 95
- Leave message/advisory message, code *69/#69 → Page 70
- Group call, code *85/#85 → Page 95
- Reset services and functions, code #0 → Page 76
- Control relays, code *90/#90 → Page 80
- Night answer, code *44/#44 → Page 54
- Timed reminders, code *46/#46 → Page 68

Open the menu → Page 19.

Select and confirm the option shown.

Confirm the option shown.

Enter the internal station number of the phone for which you wish to activate the function.

Enter code (for example, *97 for "Do not disturb on").

For any additional input, follow the instructions on your display.

1. "Differing display views in a HiPath 4000 environment" → Page 113

Using system functions from outside DISA (Direct Inward System Access)

If configured (consult your administrator), you can use an external phone like an internal station to set up an outgoing external connection via the system. You can also activate or deactivate the following system functions:

- Reset services and functions, code #0 → Page 76
- Call forwarding, code *1/#1 → Page 28
- Lock and unlock phone, code *66/#66 → Page 66
- Save your PIN code, code *93 → Page 67
- Send a message, code *68/#68 → Page 69
- Leave message/advisory message, code *69/#69 → Page 70
- Ringing group, code *81/#81 → Page 95
- Group call, code *85/#85 → Page 95
- Caller ID suppression, code *86/#86 → Page 64
- Camp-on tone, code *87/#87 → Page 47
- Open door, code *61 → Page 36
- Release door opener, code *89/#89 → Page 36
- Control relays, code *90/#90 → Page 80
- Do not disturb, code *97/#97 → Page 64
- Ringer cutoff, code *98/#98 → Page 63
- Dial using speed dial, code *7 → Page 42
- Associated service, code *83 → Page 76

Prerequisite: Your phone supports tone dialing (DTMF) or you can switch your phone to tone dialing. The phone is not connected to the system.



Establish a connection to the system. Enter the station number (consult your administrator).



Wait for the continuous tone (if necessary, switch phone to tone dialing) and enter the internal number assigned to you and the corresponding PIN code.



Enter the code (only required if programmed in the system).



Wait for the dial tone and enter the code for example, *97 for Do not disturb on. If necessary, make further entries; refer also to the user guide for dial pulse/DTMF phones.

or



Dial the external number.



You can only perform one function/establish one outgoing connection at a time.

The connection is cleared as soon as the function is successfully activated.

In the case of an external call, the connection is cleared as soon as one of the call partners hangs up.

Using functions in ISDN via code dialing (keypad dialing)

If authorized (consult your administrator), you can access ISDN functions in some regions using codes.

Open the menu → Page 19.

Select and confirm the option shown.

Confirm the option shown.


Enter the required trunk number (consult your administrator).

Enter a code for the required ISDN function (consult your administrator).



Contact your network provider to find out which ISDN functions can be code-operated in your country.

Unify GmbH & Co. KG shall not be liable for damages/costs that may be incurred by fraudulent activities or remote operation (such as toll fraud).



Controlling connected computers/programs/telephone data service

If this function has been configured (consult your administrator), you can control connected computers or programs running on them, such as hotel services or information systems, from your telephone.

Prerequisite: You have set up a connection.

Open the menu → Page 19.

Select and confirm the option shown.

Confirm the option shown.

For entering data, you are guided by the connected computer. However, depending on the configuration (consult your administrator), you have to enter your data in one of the following ways:

Input in en-bloc mode:

Enter data.

Complete entry.

Confirm the option shown.

Input in online mode:

The connected computer processes your entries directly.

Enter the code.

Enter data.

The screenshot shows a telephone interface with the following elements:

- A menu icon (three horizontal lines) in the top right corner.
- A dropdown menu labeled "Program/Service?" with a downward arrow.
- A text field displaying "*42=Tel. data service?".
- Below the text field, there are two options:
 - Option 1: A button with a square icon and a plus sign, followed by an ellipsis and a button with a square icon and the letters "wxyz".
 - Option 2: A button with a hash symbol and a square icon, followed by a minus sign and a circle.
- The word "or" is displayed between the two options.
- Option 3: A text field labeled "Entry complete?".
- Below the text field, there are two options:
 - Option 4: A button with a hash symbol and a square icon, followed by a minus sign and a circle.
 - Option 5: A button with a square icon and a plus sign, followed by an ellipsis and a button with a square icon and the letters "wxyz".
- The word "or" is displayed between the two options.

Communicating with PC applications over a CSTA interface

If configured (consult your administrator), you can use your phone to communicate with PC applications (CSTA = **C**omputer **S**upported **T**elecommunications **A**pplications). You send information to the application and receive information from the application, for example, via your phone display.

Enter the code.

Enter the three-digit ID for the application you wish to control.

Use the relevant keys to communicate with the application.

Temporarily interrupting communication with the application

The phone rings. You accept the call.

The "Data I/O" key flashes: Communication with the application was automatically interrupted.

Resuming communication with the application

Press the flashing "Data I/O" key. The LED lights up.

Ending communication with the application

Select and confirm the relevant CSTA message.

Lift the handset and replace it again.

Controlling relays (only for HiPath 3000)

If this function has been configured (consult your administrator), you can use up to four relays to enable/disable different devices (such as a door opener). Depending on how you program the relays, you can activate and deactivate them manually or configure them to activate and deactivate automatically (after timeout).




Special features must be taken into consideration if your telephone operates with system networking via LAN → Page 104!

Select and confirm the option shown.

Select and confirm the option shown.

Enter the relay.



Sensors (HiPath 33x0/35x0 only)

If configured (consult your administrator), sensors are able to recognize signals, call your phone and display an appropriate message on the screen.

Paging persons (not for U.S.)

If radio paging equipment (PSE) is connected to your system (consult your administrator), you can locate people via their pocket receivers.

Pocket receivers signal a call request to the person you want to page. This person can then answer the page at the nearest phone.

Paging persons

To ensure that you can be found, you must have enabled a ringing group → Page 97, call forwarding → Page 28 or call forwarding-no answer (service engineer) to the internal station number of your PSE.


A call request is signaled automatically.

Answering the page from the nearest telephone

Lift the handset.

Enter the code.

Enter own station number.



Phonebooks

Personal phonebook

The personal phonebook is restricted to 100 entries.

Creating a new contact

You can create contacts more conveniently via the web interface → Page 114.

Open the menu → Page 19.

Select and confirm to open the local phonebook.

Select and confirm the option shown.

Fill in the three fields

- Last name
- First name
- Number

accordingly.

Select and confirm to save the phonebook entry.

Editing a contact

You can edit contacts more conveniently via the web interface → Page 114.

Open the menu → Page 19.

Select and confirm to open the local phonebook.


Select and confirm the relevant entry.

Select and confirm the option shown.

Select and confirm, for example the "Last name" field.

Change and confirm.

Select and confirm the option shown.



Deleting a contact

You can delete contacts more conveniently via the web interface → Page 114.

Open the menu → Page 19.

Select and confirm to open the local phonebook.

Select and confirm the relevant entry.

Select and confirm the option shown.

Confirm the option shown.

Select and confirm to cancel the process.

Deleting all contacts

You can delete contacts more conveniently via the web interface → Page 114.

Open the menu → Page 19.

Select and confirm to open the local phonebook.

Select and confirm the option shown.

Confirm the option shown.

Select and confirm to cancel the process.

The image shows two screenshots of a phonebook application's menu. The top screenshot illustrates the steps to delete a single contact: it starts with a 'Personal' dropdown, followed by selecting a contact 'Niels, Bohr', then a 'Delete' option, a confirmation 'Delete?', and finally a 'Cancel ?' option. The bottom screenshot shows the steps to delete all contacts: it starts with a 'Personal' dropdown, followed by selecting 'Delete all ?', then a confirmation 'Delete all entries ?', and finally a 'Cancel ?' option. Both sequences are separated by the word 'or'.


Searching for a contact

Open the menu → Page 19.

Select and confirm to open the local phonebook.


The last entry used is displayed.

Enter the first letter of the name you are searching for, e.g. K.



Q
J **K** L5 (Abc)


The first name found with the initial letter K is displayed after a short time. If you are looking for a name that begins with Kr, also enter the second letter in the search field:



QK (5)
p q **Kr** s7ß(abc)

The first name with the initial letters Kr is displayed.

You can also browse the phonebook with the navigation keys until you reach the required party → Page 15.



Corporate directory

The corporate directory is an LDAP database. You can search the database for contact entries if you can access this database over your network and your access was correctly configured by your administrator.

You can search for contacts using the name (simple search) or different criteria for an entry (advanced search), for example job title or address.

Searching for a contact

Open the menu → Page 19.

Select and confirm to open the company-wide "Corporate phonebook" directory.

Select and confirm the option shown.

The following 11 search fields can be used:

- Last name
- First name
- Office 1
- Office 2
- Mobile
- Home
- Company
- Address 1
- Address 2
- Professional role
- E-mail

Select and confirm the required search field (e.g. "Last name").

Enter a search text. If you for example only enter the first letter of the last name, all entries with this initial letter are displayed.

Select and confirm when you have completed one or more search fields. The search begins. If the entry you searched for is found, you can dial or view the entry details.

The screenshot shows a vertical menu on a light gray background. At the top right of the menu is a small icon of a document with a list. Below it is a button labeled "Corporate phonebook" with a downward arrow. Underneath is a button labeled "Find" with a downward arrow. Further down is a button labeled "Last name" with a downward arrow. To the right of the "Last name" button is a small icon of a grid with a hand cursor. At the bottom is another button labeled "Find" with a downward arrow.

Advanced phonebook editing

Viewing entries

Prerequisite: You found and selected an entry (see above).

Select and confirm the option shown. All fields of the entry are displayed.

Resetting the search fields

Prerequisite: The search fields are listed.

Select and confirm the option shown. You can now enter new search criteria for a search.

Defining a qualifier before a search

Prior to a search, you can select which qualifiers should also appear in the output list.

Select and confirm the option shown. You may choose between the following criteria:

- No qualifier
- Job function
- Address 1
- Email
- Business 1
- Mobile
- Business 2
- Private
- Company
- Address 2

Select and confirm the desired qualifier.

Select and confirm to close the list.

Details



Delete




Qualifier



OK

Back





Quick search

Open the menu → Page 19.

Select and confirm to open the company-wide phonebook.

Q

Enter the name (Abc)

Enter the first letter of the name you are looking for, e.g. "K".

QK

J K L 5 (Abc)

If you do not enter any further characters, all available names with the corresponding initial letter are displayed after a predefined period of time or after pressing to confirm.

QKr

p q r s 7 8 (abc)

You can restrict the output by entering the second and other letters.

The key is used to switch between letters and numbers.

The keys are used to delete individual characters.

You can control the search individually by entering extended characters.

To select extended characters, first press the key.

Rule list:

Character	Description
#	Searches for the exact string before the extended character.
*	Wildcard. This searches for the character entered and all possible subsequent characters.

You enter this character by selecting it in the extended characters.

Making calls in the team/executive/secretary configuration

If configured (consult your administrator), you belong to a team of subscribers with multiple lines (MultiLine → Page 12). Your phone features trunk keys (MULAP keys) → Page 89.

Lines

A distinction is made between primary and secondary lines. Each of these line types can be used on a private or shared basis → Page 88.

Primary line

All multi-line telephones have a primary line. This line can be reached in the usual manner via your public phone number. Incoming calls to your number are signaled on this line.

Secondary line

A secondary line on your phone is used as a primary line by another subscriber. Your primary line, which is configured on another telephone, simultaneously functions as the secondary line on that telephone.

Line utilization

Private line

A line that is used by a single telephone. This line cannot be used as a secondary line by another telephone.

Shared line

A line that is configured on multiple telephones. The line status is displayed for all telephones that share this line (if configured). If, for example, a shared line is being used by a telephone, a status message indicating that this line is busy is displayed on all other telephones that share this line.

Direct call line

A line with a direct connection to another telephone.
You can see the status of the line from the LED display.

Line seizure

Line seizure must be configured (consult your administrator). If automatic line seizure is configured, a trunk is automatically assigned when you lift the handset or press the speaker key.

Line/trunk keys




The programmable keys on multi-line phones function as line or trunk keys. Every key programmed as a "Trunk key" (key label: Transfer Trk) corresponds to one trunk with the result that you can configure up to eight trunks in OpenScape Desk Phone IP 35 G.

As a team member, you can independently program the following functions on keys → Page 55:

- Direct station select
- Join/leave group
(not available on executive phone in an executive / secretary team)
- Ring transfer: On/Off
(only in an executive/secretary team)

You can also program a key with the function "Forward Line" (call forwarding) for each line.


LED displays on trunk keys

LED		Meaning
	Off	– The line is in idle mode.
	Flashing ¹	– Incoming call on the line. – Hold reminder is activated. – The line is on "Hold".
	On	– The line is busy.

¹ In this manual, flashing keys are identified by this icon, regardless of the flashing interval. The flashing interval represents different statuses, which are described in detail in the corresponding sections of the manual.

Accepting calls with the trunk keys

Prerequisite: Your phone rings and/or a trunk key flashes quickly.

if nec. 

Press the trunk key that is flashing quickly.
(not necessary for automatic trunk seizure/prime line is not active).



or

Lift the handset.

On-hook dialing: Speakerphone mode.

Dialing with trunk keys

if nec. 

Press the free trunk key you wish to use to establish the connection
(not necessary for automatic trunk seizure/prime line is not active).



Dial the phone number.



or

If the party answers: Lift the handset.


On-hook dialing: Speakerphone mode.

Placing a call on hold on a trunk key and retrieving the held call

Prerequisite: You are conducting a call via one of your group's trunks. The "Hold" key has been programmed on your telephone → Page 55.

Holding

Press the "Hold" key.



Replace the handset or press the disconnect (release) key.

Depending on the configuration (consult your administrator), this may be necessary so other team members can also pick up the call on hold.

Retrieving the call

Press the trunk key that is flashing slowly.



Making calls on multiple lines alternately

Prerequisite: You are conducting a call via one of your group's trunks. Another trunk key is flashing.



Press the flashing line key. The first call party is on hold on the other trunk.



Press the trunk key that is flashing slowly. The second call party is on hold.

You can switch between lines as often as you wish. Press the trunk key flashing slowly each time.

MULAP conference release

If configured (consult your administrator), you can program a key on your phone with the function "MULAP Privacy Release" → Page 55. The default label is "Priv Release".

If you program this key, you do not have to use the menu to set up a conference. Your team partner only has to press the flashing trunk key associated with your trunk on his or her phone to immediately join the conference.



You are conducting a call.



Press the "Priv Release" key. The LED lights up.

Up to three team members can now join the conference.

Prerequisite: The trunk on which you are speaking is configured on the other phone as a trunk key.



Press the flashing line key.

Direct station selection keys

Each team member has a direct station selection key for every other team member.

This means that each team member can be reached directly by other team members at the touch of a button.

Understanding LED messages on DSS keys



LED on the DSS key is off - the team member is not conducting a phone call.

or



LED on the DSS key is lighting – the team member is conducting a phone call or has activated do not disturb.

or



LED on the DSS key is flashing **quickly** - a call has arrived for you and needs to be answered.

or




LED on the DSS key is flashing **slowly** – a caller is trying to reach another member of your team, who has not yet answered.

Using DSS keys to accept calls

Prerequisite: Your telephone rings or the DSS key flashes.

Press the flashing DSS key.

This is not necessary if you are called directly (DSS key flashes quickly).

if nec. 



Lift the handset.

or

On-hook dialing: Speakerphone mode.

Calling a team member directly



Press the DSS key.

or



If the team member you wish to reach is conducting another call, the DSS key on your telephone lights. You can still make the call in this case.



If the party answers: Lift the handset.

or

On-hook dialing: Speakerphone mode.

Transferring a call in progress

Press the DSS key and announce the call if necessary.

Replace the handset.



or



Press the key shown.

Picking up a call for another team member

Press the flashing DSS key or trunk key.

Lift the handset.

On-hook dialing: Speakerphone mode.



or



Forwarding calls on trunks

You can immediately forward internal and/or external calls to your lines to different internal or external telephones (destinations) (external destinations are also possible if the system is configured accordingly).

Activating call forwarding for one trunk activates the function for all trunk keys assigned to this trunk in your group.

Open the menu → Page 19.

Select and confirm the option shown.

Select and confirm the option shown.

If available, press the "CFW MULAP" key. (You have programmed a key with the incomplete "CFW MULAP" function, excluding the call forwarding type and destination → Page 55).

Press the required line key.

Enter the required trunk number.

Select and confirm the option shown.


Select and confirm the option shown.

Select and confirm the option shown.

Enter the destination number.

Confirm the option shown.

If available, press the "CFW MULAP" key. (You have stored the call forwarding type and destination on the "CFW MULAP" key → Page 55.)



Deactivating call forwarding

Open the menu → Page 19.

Select and confirm the option shown.

Select and confirm the option shown.

Press the required line key.

Enter the required trunk number.

If available, press the "CFW MULAP" key.



If you have activated call forwarding for a trunk, a special dial tone sounds when the line is seized.

Understanding LED messages on the "CFW MULAP" key

The LED on the "CFW MULAP" key is off – call forwarding is not active for this trunk.

The LED on the "CFW MULAP" key lights up – call forwarding is active for this trunk.

The LED on the "CFW MULAP" key flashes **slowly** - the trunk is the destination of call forwarding.

Transferring calls directly to the executive phone

Normally, all calls for the executive are audibly signaled only by the secretary phone.

You can set audible signaling so calls are only signaled acoustically by the executive phone or by a second phone assigned to it.

Prerequisite: There is a key programmed with the function "Ring Transfer" on your phone. The default label is "Ring xfer".

Activating

Press the "Ring xfer" key. The LED lights up.

Open the menu → Page 19.

Select and confirm the option shown.

Select and confirm the option shown.

Press the required line key.

Enter the required trunk number.

Deactivating

Press the "Ring xfer" key. The LED goes out.


Open the menu → Page 19.

Select and confirm the option shown.

Select and confirm the option shown.

Press the required line key.

Enter the required trunk number.



Using team functions

If configured (consult your administrator), your telephone is part of a team. The team consists of internal phones that are able to use certain functions.

Activating/deactivating a group call



Special features must be taken into consideration if your telephone operates with system networking via LAN → Page 100!

If configured (consult your administrator), you belong to one or more groups of stations, which can be reached via hunt group or group call station numbers. Incoming calls are signaled one after the other (= hunt group) or simultaneously (= group call) on all phones in the group, until a group member answers the call.

Each station in the group can still be reached via its own station number.

You can activate and deactivate the audible signal for a hunt group, group call or individual trunks in a group.

You are part of a hunt group or call group

Open the idle menu → Page 16.

Select and confirm the option shown¹.

Select and confirm the option shown.

Press the "Group call" key.



Leave group?

or

Join group?

☒ or ☐

1. "Differing display views in a HiPath 4000 environment" → Page 113

You belong to multiple groups

Open the idle menu → Page 16.

Select and confirm the option shown^[1].

Select and confirm the option shown.

Press the "Group call" key.

If an "X" appears between group/trunk number (such as 301) and group name, the audible tone is active for this group or trunk.

No "X" means that the audible tone is deactivated.

Confirm the option shown. The next group/trunk number is displayed with a group name.

Select and confirm the option shown¹.
The audible tone for the group/trunk displayed is deactivated.

Select and confirm the option shown^[1].
The audible tone for the group/trunk displayed is activated.

Select and confirm the option shown.
The audible tone for all groups and trunks is deactivated.

Select and confirm the option shown.
The audible tone for all groups and trunks is activated.



If you have activated the audible tone for another group/trunk or deactivated the audible tone for all groups/trunks you belong to, you will hear a special dial tone when you lift the handset.

1. "Differing display views in a HiPath 4000 environment" → Page 113

Picking up a call for another member of your team

You can use your own telephone to pick up calls for other telephones in your team, even while on a call (call pickup groups; consult your administrator).

Prerequisite: Your telephone rings briefly. "Call for:" appears on the upper display line with the station number or name of the originator; the station number or name of the caller appears on the lower line.

Confirm the option shown.

Pickup - group?

Ringling group

You can have calls for your telephone signaled audibly at up to five other internal phones. The phone that answers the call first receives the call.



Special features must be taken into consideration if your telephone operates with system networking via LAN → Page 103!

Saving, displaying and deleting telephones for the ringing group

Open the menu → Page 19.

Select and confirm the option shown.

Program/Service?



*81=Ringling group on?

Select and confirm the option shown.

Follow the display prompts (enter the internal station number).



If your phone belongs to a ringing group, your display will show the station number or the name of the initiator on the upper line and that of the caller on the lower line.

Removing all telephones in a call ringing group

Select and confirm the option shown.

Ringling group off?

Uniform Call Distribution (UCD)

If configured (consult your administrator), you may belong to a group of stations (agents), to which calls are distributed.

An incoming call is always assigned to the agent idle the longest.

Logging on and off at the beginning and end of your shift

Open the menu → Page 19.

Select and confirm the option shown.

Select and confirm the option shown.

Confirm the option shown.

Select and confirm the option shown.

To log on, enter your identification number ("Agent:"). Consult your administrator to find out what it is.

Logging on and off during your shift

Open the menu → Page 19.

Select and confirm the option shown.

Select and confirm the option shown.

Confirm the option shown.

Select and confirm the option shown.

The screenshot displays a vertical menu interface with two distinct sections. Each section begins with a hamburger menu icon (three horizontal lines) in the top right corner. The first section contains a dropdown menu labeled 'Program/Service?' with a downward arrow, followed by a text field labeled 'UCD?'. Below this is another text field labeled '*401=Log on?'. A separator line with the word 'or' in the center follows. The second text field in this section is labeled '#401=Log off?'. A small icon of a hand pointing at a screen is located below the text fields. The second section also starts with a hamburger menu icon, followed by a 'Program/Service?' dropdown, a 'UCD?' dropdown with a double-headed arrow, a text field labeled '#402=Not available?', a separator line with 'or', and a final text field labeled '*402=Available?'.

Requesting and activating work time

You can request/activate work time to ensure you have enough time to wrap up the last call. Your phone is excluded from call distribution for a set period or until you log back on.

Open the menu → Page 19.

Select and confirm the option shown.

Select and confirm the option shown.

Confirm the option shown.

Select and confirm the option shown.

Turning the night service on and off for UCD

Open the menu → Page 19.

Select and confirm the option shown.

Select and confirm the option shown.

Confirm the option shown.

Select and confirm the option shown.

Display the number of waiting calls

Open the menu → Page 19.

Select and confirm the option shown.

Select and confirm the option shown.

Confirm the option shown.

The image displays three sequential screenshots of a mobile application interface, each showing a menu with three options. Each screenshot begins with a hamburger menu icon in the top right corner.

First Screenshot: The menu options are "Program/Service?", "UCD?", and "*403=Work on?". Below these options is the word "or".

Second Screenshot: The menu options are "Program/Service?", "UCD?", and "*404=UCD night on?". Below these options is the word "or".

Third Screenshot: The menu options are "Program/Service?", "UCD?", and "*405=Calls in queue?".

Special functions in the LAN

If your telephone is operating in an environment in which multiple HiPath 3000/ OpenScape Business and/or OpenScape Office MX/LX systems are interconnected via a LAN (Local Area Network, such as a proprietary PC network), you are conducting a call via the LAN (PC network).

In this instance, you must note certain particularities for some functions. These are described in this section.

Leaving hunt group/group call

Prerequisite: You are part of a hunt group/group call → Page 95 in another HiPath 3000/OpenScape Business or OpenScape Office MX/LX.

Open the idle menu → Page 16.

Select and confirm the option shown.

Enter the (DISA) call number of the other HiPath 3000/OpenScape Business or OpenScape Office MX/LX.

Confirm your entry.

Enter the (DISA) station number of your phone.


Confirm your entry.

Select and confirm the option shown.

Select and confirm the option shown.

You belong to multiple groups associated with another HiPath 3000/OpenScape Business or OpenScape Office MX/LX

Enter the group number for "directed joining/leaving".



Setting up "follow me" call forwarding

You can activate/deactivate call forwarding → Page 28 for your phone from other phones in the LAN.

Open the idle menu → Page 16.

Select and confirm the option shown.

(DISA) station number of your HiPath 3000/OpenScope Business or OpenScope Office MX/LX.

Confirm your entry.

Enter the (DISA) station number of your phone.

Confirm your entry.

Activating

Open the idle menu → Page 16.

Select and confirm the option shown.

Confirm the option shown.

Select and confirm the option shown.

Select and confirm the option shown.

Enter the destination phone number.

Confirm the option shown.

Deactivating

Open the idle menu → Page 16.

Select and confirm the option shown.

The screenshot shows a vertical menu on a light gray background. At the top is a dropdown arrow. Below it is a text box labeled "DISA internal?". To the right of this box is a small grid icon with a hand cursor. Below the grid icon are two buttons: "OK" and a button with a hash symbol and a right arrow. Below these are another grid icon and another "OK" button. Further down is another dropdown arrow. Below it is a text box labeled "Forwarding on?". Below this is another text box labeled "1=all calls?". To the right of this box is the word "or". Below "or" is a text box labeled "2=external calls only?". Below this is another "or". Below "or" is a text box labeled "3=internal calls only?". To the right of this box is a small grid icon with a hand cursor. Below the grid icon is a text box labeled "Save?". At the bottom is another dropdown arrow. Below it is a text box labeled "Forwarding off?".

Using night answer

If authorized (consult your administrator), you can define telephones in other HiPath 3000/OpenScape Business or OpenScape Office MX/LX communication platforms as the night answer → Page 54.

Open the idle menu → Page 16.

Select and confirm the option shown.

Enter the (DISA) number of the HiPath 3000/OpenScape Business or OpenScape Office MX/LX to which the night answer phone is connected.

Confirm your entry.

Enter the (DISA) station number of the phone you wish to use to activate/deactivate night answer.

Confirm your entry.

Activating

Open the idle menu → Page 16.

Select and confirm the option shown.

Enter the destination number (= temporary night answer service).

Confirm the option shown.

Deactivating

Open the idle menu → Page 16.

Select and confirm the option shown.

The screenshot displays a vertical sequence of configuration screens on a light gray background. Each screen features a small downward arrow icon in the top right corner. The screens are as follows:

- DISA internal?**: A text input field with a numeric keypad icon to its right.
- OK or #**: A screen with two buttons, 'OK' and '#', separated by the word 'or'.
- OK or #**: A second screen identical to the previous one.
- Night answer on?**: A text input field with a numeric keypad icon to its right.
- Save?**: A text input field.
- Night answer off?**: A text input field.

Ringing group

You can have calls for your telephone signaled audibly at external telephones or at telephones in other HiPath 3000/OpenScape Business or OpenScape Office MX/LX communication platforms → Page 97.

Saving, displaying and deleting telephones for the ringing group

Open the menu → Page 19.

Select and confirm the option shown.

Select and confirm the option shown.

Select and confirm the option shown.

Select and confirm the option shown.

Select and confirm, then follow the operating instructions.

Enter the phone number.

Confirm the option shown.

Confirm the option shown.

Select and confirm the option shown.

Removing all telephones in a call ringing group

Open the idle menu → Page 16.

Select and confirm the option shown.

The screenshot shows a vertical menu with the following options and icons:

- >≡ (Menu icon)
- Program/Service? (Dropdown arrow)
- *81=Ringing group on? (Text)
- Add to ringing group? (Text)
- or (Text)
- Add another station? (Text)
- or (Text)
- Display/remove? (Text)
- ⌨ (Keypad icon)
- #=Entry complete? (Text)
- Save? (Text)
- Exit? (Text)
- ▼ (Dropdown arrow)
- Ringing group off? (Text)

Controlling relays (only for HiPath 3000)

If this feature is configured (consult your administrator), you can also control relays
→ Page 80 in other HiPath 3000 communication platforms.

Open the idle menu → Page 16.

Select and confirm the option shown.

Enter the (DISA) station number of the HiPath 3000 where you wish to control the relay.

Confirm your entry.

Enter the (DISA) station number of the phone you wish to use to control the relay.

Confirm your entry.

Confirm the option shown.

Select and confirm the option shown.

Enter the relay.

Opening a door

If this feature is configured (consult your administrator), you can also activate the door opener → Page 36 in other HiPath 3000/OpenScape Business or OpenScape Office MX/LX communication platforms.

Open the idle menu → Page 16.

Select and confirm the option shown.

Enter the (DISA) station number of the HiPath 3000/OpenScape Business or OpenScape Office MX/LX where you wish to control the relay.


Confirm your entry.

Enter the (DISA) station number of the phone you wish to use to control the door opener.

Confirm your entry.

Select and confirm the option shown.

Dial the entrance telephone number.



Individual phone configuration

Setting contrast

The display has four contrast levels that you can set according to your light conditions.

Press one of the keys shown in idle mode.

Select and confirm the option shown.

Change the display contrast. Press the key repeatedly until the desired level is obtained.

Save.

Audio

Setting the ringer mode

You can use the two ringer mode options

- HiPath
- Local ringer

to decide how the ring tone is generated on the telephone. With the setting "HiPath", the system sends the ring tone type and the dependent ring tone, which you can adjust subsequently → Page 106.

If "Local ringer" is selected, the system sends the ring tone type and you select which ring tone is required for the respective ring tone type in the "Local ringers" menu → Page 108.

You can also configure the following setting via the web interface → Page 114.

Open the menu → Page 19.

Select and confirm the option shown.

Enter and confirm the user password.

Select and confirm the option shown.

Select and confirm the option shown.

Select and confirm the option shown.

Select and confirm the option shown.

Select and confirm the option shown.

The screenshot shows a vertical menu of configuration options. At the top, there are buttons for '+', 'or', and '-'. Below these is a button labeled 'Display contrast?'. Further down are more '+', 'or', '-' buttons, followed by an 'OK' button. A small icon of a list with three items is visible. Below that is a button labeled 'User ?' with a dropdown arrow. A note 'if nec.' is followed by a small icon of a keypad. Below this is a button labeled 'Ringer ?' with a dropdown arrow. Another button labeled 'Ringer mode ?' with a dropdown arrow follows. Then a button labeled 'HiPath?' with a dropdown arrow. Below this is the word 'or'. Then a button labeled 'Local.ringer ?' with a dropdown arrow. Finally, a button labeled 'Option = Save & exit?' with a dropdown arrow.

Adjusting audio settings

The ringer mode "HiPath" is set. The OpenScape Business sends the ring tone type and the ring tone setting to your telephone.

Optimize the audio settings on your OpenScape Desk Phone IP 35 G for your work environment and according to your personal requirements.

Adjusting the receiving volume during a call

You are conducting a call.

Raise or lower the volume. Keep pressing the key until the desired volume is set.
Save.

Adjusting the ring volume

Press one of the keys shown in idle mode → Page 16.

Confirm the option shown.

Raise or lower the volume. Keep pressing the key until the desired volume is set.
Save.

Adjusting the ringer pitch

Press one of the keys shown in idle mode → Page 16.

Select and confirm the option shown.

To adjust the ringer pitch: Keep pressing the keys until the desired pitch is set.
Save.

Adjusting the attention ring volume

If you are part of a team with trunk keys, other calls can be signaled acoustically in the team during a call. You will hear the attention ring.

Press one of the keys shown in idle mode → Page 16.

Select and confirm the option shown.

Raise or lower the volume. Keep pressing the key until the desired volume is set.
Save.

+

 or

-

OK

+

 or

-

Ring volume?
+ or

-

OK

+

 or

-

Ring tone?
+ or

-

OK

+

 or

-

Attention Ring Vol.
+ or

-

OK

Adjusting the speakerphone to the room acoustics

To help the other party understand you clearly while you are talking into the microphone, you can adjust the telephone to the acoustics in your environment: "T0343 Quiet room", "T0344 Normal room" and "T0345 Noisy room."

Press one of the keys shown in idle mode → Page 16.

Select and confirm the option shown.

To set the room type: Keep pressing these keys until the setting you want appears on the screen.

Save.

Language for system functions

Open the menu → Page 19.

Select and confirm the option shown.

Select and confirm the option shown.

Select and confirm the option shown.

Select the language you wish to use (e. g. "Spanish") and confirm.

[+] or [-]

Speakerphone mode?

[+] or [-]

OK

☰

Program/Service?

More features?

*48= Select language?

15=Spanish?

Setting local ring tones

Selecting and configuring the call type

The ringer mode "Local ringer" is set. Different ring tone types are sent by the OpenScape Business/HiPath 3000. Not all of the following types will necessarily be used in your system configuration:

- 1: Internal
- External Call
- Attention Ringer

Select the required call type and adjust to suit your requirements.

You can also configure the following setting via the web interface → Page 114.

Open the menu → Page 19.

Select and confirm the option shown.

Enter and confirm the user password.

Select and confirm the option shown.

Select and confirm the option shown.

For instance, select "1: Internal" and confirm the option shown.

Select the required ringer file^[1] or "pattern". You will hear the associated ring tone melody. Confirm the current ringer file.

Settings for the ring tone "pattern"

If you selected "Pattern" as the ring tone, you can still make settings for the pattern melody and the pattern sequence:

Select and confirm the option shown.

Select the required pattern melody between 1 and 8 (e.g. **4**). You will hear the associated Ringer melody. Confirm the selected Ringer melody.

Select and confirm the option shown.

Select the required Ringer sequence between 1 and 6 (e.g. **2**). You will hear the set Ringer melody with the selected Ringer sequence. Confirm the selected setting.

Select and confirm the option shown.

1. The phone displays the current setting

Setting headset port use

Here you set whether you are using a wired or cordless DECT headset.

You can also configure the following setting via the web interface → Page 114.

Open the menu → Page 19.

Select and confirm the option shown.

Enter and confirm the user password.

Select and confirm the option shown.

Select and confirm the option shown.

Select the option shown.

Select and confirm the relevant option¹ shown in the context menu:

- Wired headset
- Cordless headset
- Conference unit

Select and confirm the option shown.

The screenshot shows a vertical menu on a light gray background. At the top right of the menu are two icons: a list icon and a back icon. Below these are several menu items, each in a rectangular box with a small arrow on the right. The items are: 'User', 'Audio', 'Settings', 'Headset socket', 'Wired headset', and 'Option = Save & exit?'. Between the 'User' and 'Audio' items, there is a small icon of a keypad and the text 'if nec.'.

1. The phone displays the current setting

Changing the user password

Your User password allows you to protect your user-defined settings.

The User password can also be modified via the web interface → Page 114.

Open the menu → Page 19.

Select and confirm the option shown.

Enter and confirm the user password.

Select and confirm the option shown.

Select and confirm the option shown.

Enter the current password (at least six characters) and confirm your entry.


Select and confirm the option shown.

Enter the new password (at least six characters) and confirm your entry.

Select and confirm the option shown.

Enter and confirm the new password once more.

Select and confirm the option shown.



The screenshot shows a vertical menu with the following options and icons:

- User** (dropdown arrow icon)
- if nec.** (grid icon)
- Change user password** (dropdown arrow icon)
- Current Password** (dropdown arrow icon)
- (grid icon)
- New user password** (dropdown arrow icon)
- (grid icon)
- Confirm new user password** (dropdown arrow icon)
- (grid icon)
- Option = Save & exit?** (dropdown arrow icon)

Network information

This overview in the user area of the menu provides you with information about the IP address of the phone and the HTML address of the web interface. It also provides real-time data about the network activity of the phone.

Open the menu → Page 19.

Select and confirm the option shown.

Enter and confirm the user password.

Select and confirm the option shown. You can browse the following overview:

IP address: Displays the IP address or name that was assigned to the phone in the network.


WBM URL: HTTP address of the web interface. This address is specified in the address line of the Internet browser and is used to call the web interface of the phone in the browser.

LAN/PC byte input: The network or PC interface data packets received are illustrated dynamically as columns.

LAN/PC byte output: The network or PC interface data packets sent are illustrated dynamically as columns.

LAN/PC autonegotiated: [Yes|No]: Displays whether the network or PC interface data transfer rate is set to automatic (**Yes**) or manual (**No**).

LAN/PC port speed: [10|100|1000] Mbit/s: Data transfer rate of the network or PC interface. If an interface is not in use, **Link down** is displayed.



Testing the phone

Testing the phone's functionality

You can test your phone's functionality.

Prerequisite: The phone is in idle mode.

Open the menu → Page 19.

Select and confirm the option shown.

Select and confirm the option shown.

Select and confirm the option shown.

If everything is functioning correctly:

- All LEDs on the phone flash (only the menu key LED is continuously lit)
- Your station number is displayed
- All pixels are active on the display
- The ring tone is audible

Checking the key assignment

You can check the key assignment on your phone to determine which functions are assigned to which keys.

Open the menu → Page 19.

Select and confirm the option shown.

Select and confirm the option shown.

Press any key. The key assignment is displayed.

Select and confirm the option shown.

The image displays two screenshots of a phone's menu interface. The top screenshot shows a menu with three options: 'Program/Service?' (with a dropdown arrow), 'More features?' (with a double arrow), and '*940=Phone test?'. The bottom screenshot shows a similar menu with three options: 'Program/Service?' (with a dropdown arrow), 'Prog. feature key', and 'Exit'.

Differing display views in a HiPath 4000 environment

Depending on the system configuration, some functions may not always be offered in the display as described in this document.

In addition, display texts may differ from those described in this document depending on the system configuration.

The following table provides an overview:


HiPath 3000/Open-Scape Business OpenScape Office display	HiPath 4000 display	Description
Program/Service	Service menu?	→ Page 19
Transfer	Transfer?	→ Page 27
View callbacks	Show callback destinations?	→ Page 33
Pickup - directed	Directed pickup	→ Page 34
Caller list	Call list/log?	→ Page 38
Use speed dialing	Use speed dialing?	→ Page 42
Change speed dial	Speed dial?	
Call waiting trm.	Second call release?	→ Page 47
Call wait.trm. on/off	Second call on/off?	
Ringer cutoff on/off	Ringer cutoff on/off?	→ Page 63
Join/leave group	Hunt group on/off?	→ Page 95

Web interface

General

You can configure a number of settings for your phone via the web interface. Communication is via a secure HTTPS connection. Access to the web interface must be activated by your administrator.

Launching the web interface

 For more information about the IP address, the web interface address and how to connect the telephone to the network, refer to the section entitled "Network information" → Page 111.

To launch the interface, open a web browser and enter the following:


https://[IP address of the phone]

[IP address of the phone] is the IP address of your phone.

or

https://[Name of the phone]

[Name of the phone] that was assigned by the administrator.

 You might receive a certificate notification from the browser. Follow the instructions to download the certificate.

You will be prompted to configure a user password → Page 110 the first time you call up the web interface. You must log in with this password in future every time you want to open the User Pages.

Administrator Pages

This area lets you configure settings for administering your phone and the network environment. Access to the Administrator Pages is protected by the admin password. For further information, consult your administrator or refer to the administration manual.

User Pages

The web interface homepage opens once you have entered and confirmed the phone's IP address.

1. Click a menu heading to display the individual menu entries. Click the menu heading again to close the menu.
2. Click a menu entry to open the corresponding form.
3. Make the desired changes.
4. Click the corresponding button to save or discard your changes.

Button functions

- "Login": Log in to the phone after you have entered the user password
- "Submit": Apply changes
- "Reset": Reset original values
- "Refresh": Update the values
- "Logout": Log out from the phone


User menu

All settings in the user menu of the web interface can also be made via the user menu on the telephone.



User Pages

User login  → Page 110


Authentication  → Page 110

- Old password
- User password  → Page 110
- Confirm password




Ringer

- Ringer mode ( → Page 105)
 - HiPath
 - Local ringer
- Local ringers  → Page 108
 - Name
 - 1: Internal
 - Ringer file
 - Pattern melody
 - Pattern sequence
 - External Call
 - Ringer file
 - Pattern melody
 - Pattern sequence
 - Attention Ringer
 - Ringer file
 - Pattern melody
 - Pattern sequence

Audio

- Settings
- Headset socket ( → Page 109)

Phonebook

- Contact list  → Page 82
- New contact  → Page 82
 - Last name
 - First name
 - Number
- Delete all contacts  → Page 83
 - Confirm delete

Fixing problems

Responding to error messages

Incorrect input

Possible causes:

Station number is incorrect.

Possible reactions:

Enter correct station number.

Not authorized

Possible causes:

Locked function selected.

Possible reactions:

Apply to the administrator for authorization for relevant function.

Currently not possible

Possible causes:

Dialed a non-existent station number. Called phone is unplugged.

Possible reactions:

Enter correct station number. Call this station again later.

Invalid station number

Possible causes:

Dialed your own station number.

Possible reactions:

Enter correct station number.

Contact partner in case of problems

Consult your administrator if a fault persists for more than five minutes, for example.

Troubleshooting

Pressed key does not respond:

Check if the key is stuck.

Telephone does not ring:

Check whether the "Do not disturb" function is activated on your telephone (→ Page 64). If so, deactivate it.

You cannot dial an external number:

Check whether your telephone is locked.

If the phone is locked, enter your PIN to unlock it → Page 66.

To correct any other problems:

First consult your administrator. If the problem still cannot be resolved, the administrator has to contact Customer Service.

Care and cleaning instructions

- Never spray the phone with liquids as the penetrating fluids can lead to malfunctions or may damage the device.
- Clean the phone with a soft and slightly damp cloth.
- Do not use substances such as alcohol, chemicals, household cleaners or solvents, as these substances can lead to surface damage or cause the coating to peel.

Labeling keys


The following options are available for labeling keys of the OpenScape Desk Phone IP 35 G with the functions or numbers assigned to them:

Labeling

- By hand:
Labeling strips for your OpenScape Desk Phone IP 35 G are optional available (ask your service personnel). Note the function or name in the white field on the strip and insert the strip on your OpenScape Desk Phone IP 35 G.
- With a computer via the Internet:
You can find the "online labeling tool" together with the user interface at http://wiki.unify/index.php/Key_Labelling_Tool.
- Select the appropriate key labeling tool in your language. You can use the tool online via the browser or you can download it for local use.

Local user menu

Opening the user menu on the phone

To open the user menu, press the  key.

Select the **User** menu option. You are prompted to enter the User password → Page 110. Confirm this with **OK**. The options of the user menu are available.

User menu display

The majority of settings that can be made via the user menu on the phone can also be made via the web interface → Page 114.

Changes are usually confirmed using the **Save & exit** option or discarded using the **Exit (no save)** option.

User

Ringer?

- Local Ringers? → Page 108
 - 1: 1: Internal
 - Option = Save & exit
 - Name = 1: Internal
 - Ringer sound = Ring file
 - Pattern melody = 2
 - Pattern sequence = 2
 - 2: External Call
 - Option = Save & exit
 - Name = External Call
 - Ringer sound = Ring file
 - Pattern melody = 2
 - Pattern sequence = 2
 - 3: Attention Ringer
 - Option = Save & exit
 - Name = Attention Ringer
 - Ringer sound = Ring file
 - Pattern melody = 2
 - Pattern sequence = 2
- Ringer mode? → Page 105
 - Option = Save & exit
 - Mode = HiPath
 - Local.ringer?
 - Back?

Audio?

- Settings? → Page 109
 - Headset socket
 - Wired headset
 - Cordless headset
 - Conference unit

Change user password?

- Current password = → Page 110
- New user password =
- Confirm password =
- Option = Save & exit

Network information?

- Option = Exit
- Phone address = → Page 111
- Web address =
- IPv4 address =
- LAN RX =
- LAN TX =
- PC RX =
- PC TX =
- LAN autonegotiated = Yes
- LAN information = 10 Mbps full duplex
- PC autonegotiated = Yes
- PC information = Link down
- Back?

Index

A

Absence text	70
Leaving	70
Activating door opener	36
Administrator	19
Advisory message	
Delete	71
Agents	98
Announcement	43
Answering machine	75
Assigning a DID number	45
Associated dialing/dialing aid	45
Associated service	76
Attention ring volume	106
Automatic call waiting	
Preventing/allowing	47
Automatic connection setup	44
Automatic trunk seizure/prime line is not active	25

C

Call	
Accepting	22
Directed pickup	34
Distributing	98
Ending	24
Entrance telephone	35
Forwarding	28
Forwarding in a team	92
Forwarding MSN in CO	31
In a team with trunk keys	89
Parking	48
Picking up in a group	97
Picking up in a team	92
Placing on hold	49
Recording	52
Rejecting	26
Retrieving from hold	49
Retrieving from park	48
Transferring	27, 92
Transferring after announcement	52
Using DSS keys in a team	91
Call charge assignment	61
Call charges	
For another phone	60
For your phone	60
Call duration	60
Call forwarding	28
In the event of telephone failure	30
MSN in CO	31
Call list	18

Call request	18
Call signal	22
Call volume	22, 106
Call waiting	53
Accepting	46
Tone off	47
Call waiting tone on/off	47
Callback	32
Caller ID suppression	64
Caller list, using	38
Calling a second party	27
Calls in queue	71, 98
CE marking	3
Central telephone lock	66
CFNR	29
Charges	
For another phone	60
For your phone	60
Checking the key assignment	112
Cleaning information	118
Code dialing in ISDN	78
Code lock	
Central	66
For phone	66
Company	19
Conference	27
Connection options	21
Connection setup	
Automatic	44
Consultation	27
Control relays	80
Corporate directory	85
CSTA	80

D

Details, fax	75
Dialed number, editing	37
Dialing	
Dialing aid	45
En-bloc	37
From the caller list	38
From the internal phonebook	39
From the LDAP database	40
Internal / external	25
On-hook	25
Using redial	26
Using repdial keys	26
Using speed dialing	42
Dialing aid	
S0 bus	45
Dialing external calls	25
Dialing internal calls	25
Dialing the CO	25
Dialpad	16
Differences	11

Direct Inward System Access	77
Direct station select	56, 91
Directory	
LDAP	85
Local phonebook	
New contact	82
Directory LDAP	40
DISA	77
Discreet calling	44
Display contrast	105
Display views for	
HiPath 4000 environment	113
Distributing calls	98
Do not disturb	64
Door opener	36
DTMF suffix dialing (tone dialing)	51

E

Editing a dialed number	37
Editing number	37
En-bloc dialing	37
Encrypted call	62
Entrance telephone	35
External code	25

F

Fax details	75
Forwarding	28
Multiple subscriber number (MSN)	31
Forwarding MSN in CO	31
Forwarding multiple subscriber number (MSN)	31
Function key	
Programmable	15
Functions	
For another phone on/off	76
Programming a key	55
Resetting	76
Using from externally	77

G

General information	10
Group call	95

H

Handsfree answerback	35
Disabling	35
Enabling	35
Headset	34
HiPath 3000	
Control relays	104
Relays	104
HiPath 5000	
Group call	100
Hunt group	100
Night answer	102
Opening a door	104
Ringing group	103
Setting up "follow me" call forwarding	101
Holding	49
In the team	90
Hot line	44
Hotline delayed	44
Hunt group	95

I

Idle mode	16
Important information	4
Incoming calls	18
Internal phonebook	39
IP telephony	100

K

Keypad dialing	78
Keys	
Assigning	55
Programming	55
Save incomplete	55

L

LAN telephony	100
LDAP	85
LDAP directory	40
LED displays	
DSS keys	15
Function keys	15
Line/trunk keys	89
LED messages, understanding	56, 91, 93
Line key	89
Line utilization	88
Location of the telephone	4
Locking/unlocking	66
Loudspeaker	23

M

Making mobile calls	71
Menu	19
Message (text)	
Answering	70
Deleting/viewing	69
Receiving	70
Sending	69
Microphone	24
MULAP keys, trunk keys	88
MULAP privacy release	90
MultiLine phone	12

N

Name plate	11
Night answer	54
Non-secure call	11, 62

O

Open listening	24
Opening a door	36
Using a code	36
OpenScape Desk Phone IP 35 G	
Speakerphone mode	23
Adjusting the room acoustics	107
Tips	11, 23
Operating instructions	3
Operating steps	
Programming a key	58
Outgoing calls	18
Overload indication	71
Override	53

P

Parking a call	48
Personal	19
Personal identification number	67
Phone	
Locking	66
Locking another	66
Locking/unlocking	66
Locking/unlocking centrally	66
Setting	105
Testing	112
Using another phone like your own	71
Phone settings	105
Picking up (call)	34, 97
PIN	67
PIN, saving	67
Primary line	88
Private line	88
Procedure	
Programming a key	58
Product name	11
Product variants	11
Program/Service menu	19
Programmable function key	15
Programming free keys	55
Programming your telephone	105
Project calls	61
Project code, account code	61

Q

Quick search	87
--------------------	----

R

Radio paging equipment (PSE)	81
Recall	52
Receiving volume	22, 106
Recording	52
Redialing a number	26
From the caller list	38
Relays	80
Reserve trunk	44
Reserving trunk	44
Resetting functions	76
Resetting services	76
Ring tone	106
Ring transfer	
In an executive/secretary team	94
Ring volume	106
Ringer cutoff	63
Ringing group	97
Room monitor	65
Room monitoring	65

S

Safety notes	3
Searching for a contact	84, 85
Second call	
Accepting	46
Allowing	47
Preventing	47
Second level	26
Secondary line	88
Secure call	11, 62
Connection status	63
Encrypted call	62
Tips	63
Unencrypted call	62
Sensors	81
Serial number	11
Setting headset port	109
Settings	105
Settings on your telephone	105
Shared line	88
Shift	26
Shift key	26
SingleLine phone	12
Speaker call	43
Speakerphone distance	4
Speakerphone mode	
Adjusting the room acoustics	107
Function	23
Setting the volume	107
Tips	11, 23
Special dial tone	64
Speed dial	
Dialing	42
Saving station speed dialing	42
Suffix dialing	42
System	42
Station number	
Assigning	45
Correcting	37
Deactivating display	64
Saving	59
Suppression	64
Station speed dialing	42
Suffix dialing	
Automatic	42
DTMF tone dialing	51
System speed dialing	42
System-wide cancelation	76

T

Telephone data service	79
Telephone maintenance	118
Telephone test	112
Temporary phone	71
Testing the phone's functionality	112
Testing the telephone	112
Three-party conference	27
Timed reminder	68
Timed reminder, answering	69
Toggle/connect	27
In the team	90
Tone dialing	51
Trace call	65
Transferring (call)	27, 92
After announcement	52
Troubleshooting	118
Trunk flash	53
Trunk seizure, automatic	25

U

Unanswered calls	18
Unencrypted call	62, 63
Uniform Call Distribution	98
User	19
User interface	
OpenScape Desk Phone IP 35G	13
User password	110
User support	10
Using Ethernet switches	21
Using network ports more efficiently	21

V






Variable call forwarding	28
Voice encryption	11, 62
Connection status	63
Encrypted call	62
Tips	63
Unencrypted call	62






W






Waiting calls	71
Web interface	114, 119
Wrap-up time	99






Overview of functions and codes (alphabetical)

The following table lists all available functions, as shown on the display. If configured (consult your administrator), functions can be activated interactively (select and confirm) or via the Program/Service menu (select and confirm or enter a code).

Functions (=display)	... Interact- ively	... Via the Program/Service menu		... With key
	 	 → Page 19  	Code	
Account code		✓	*60	X
Advisory msg. on	✓	✓	*69	X
Advisory msg. off	✓	✓	#69	X
Associated dialing		✓	*67	X
Associated services		✓	*83	X
Call waiting	✓	✓	*55	X
Waiting tone off	✓	✓	*87	X
Waiting tone on	✓	✓	#87	X
Call wait.trm.on		✓	*490	X
Call wait.trm.off		✓	#490	X
Callback	✓	✓	*58	X
View callbacks/delete	✓	✓	#58	
Caller list	✓	✓	#82	X
Save number	✓	✓	*82	X
Conference	✓	✓	*3	X
Start conference	✓			
Add party	✓			
End conference	✓	✓	#3	
View conf parties	✓	✓		
Remove party	✓	✓		
Drop last conf. party			*491	
Consultation	✓			X
Return to held call	✓	✓	*0	
Quit and return	✓	✓	*0	
Transfer/Pick up call	✓			
Control Relay On (only for HiPath 3000)		✓	*90	X
Control Relay Off (only for HiPath 3000)		✓	#90	X
Data I/O service			*494	X

Functions (=display)	... Interact- ively	... Via the Program/Service menu		... With key
	 	 → Page 19  	Code	
Directory				
1=internal	✓		*54	X
2=LDAP	✓		*54	X
DISA				
DISA internal	✓	✓	*47	X
Discreet calling			*945	X
DND on	✓	✓	*97	X
DND off	✓	✓	#97	X
Door opener		✓	*61	X
Door opener on		✓	*89	X
Door opener off		✓	#89	X
DTMF dialing		✓	*53	X
En-bloc dialing				
Dialing	✓			
Forwarding on	✓	✓	*1	X
1=all calls	✓	✓	*11	X
2=external calls only	✓	✓	*12	X
3=internal calls only	✓	✓	*13	X
Forwarding off	✓	✓	#1	X
CFNR on		✓	*495	X
CFNR off		✓	#495	X
Trunk FWD on	✓	✓	*64	X
Trunk FWD off	✓	✓	#64	X
Headset				X
Answer call	✓			
HF answerback on	✓	✓	*96	X
HF answerback off	✓	✓	#96	X
Hotline				
Join group	✓	✓	*85	X
Leave group	✓	✓	#85	X
Rejoin all groups	✓	✓	*85*	X
Leave all groups	✓	✓	#85#	X
Keypad dialing		✓	*503	
Lock all phones		✓	*943	X
Lock phone	✓	✓	*66	X
Unlock phone	✓	✓	#66	X
Change PIN		✓	*93	

Functions (=display)	... Interact-	... Via the		... With key
	ively  	Program/Service menu  → Page 19  	Code	
Mobile Login (log off)			#9419	X
Mobile Login (log on)			*9419	X
Mute on		✓	*52	X
Mute off		✓	#52	X
Night answer on	✓	✓	*44	X
Night answer off	✓	✓	#44	X
Override	✓	✓	*62	X
Page				
Answer page (not for U.S.)		✓	*59	
Park call		✓	*56	X
Retrieve call		✓	#56	
Phone test		✓	*940	
Pickup - directed		✓	*59	X
Pickup - group	✓	✓	*57	X
Pick up call	✓			
Show call charges (own phone)		✓	*65	X
Query call charges (third-party phone)				X
Redial	✓			X
Reject calls	✓			
Release				X
Reserve trunk	✓			X
Reset services		✓	#0	X
Retrieve line		✓	*63	X
Ring Transfer: On		✓	*502	X
Ring Transfer: Off		✓	#502	X
Ringer cutoff on	✓	✓	*98	X
Ringer cutoff off	✓	✓	#98	X
Ring group on		✓	*81	X
Ring group off		✓	#81	X
Room monitor		✓	*88	X
Select language		✓	*48	
Send message	✓	✓	*68	X
View sent message	✓	✓	#68	X
View messages	✓	✓	#68	X
Mailbox				X
Shift				X
Speaker call		✓	*80	X

Functions (=display)	... Interact- ively	... Via the Program/Service menu		... With key
	 	 → Page 19  	Code	
Suppress caller ID	✓	✓	*86	X
Restore caller ID	✓	✓	#86	X
Telephone data service			*42	
Temporary MSN (not for U.S.)	✓	✓	*41	X
Temporary phone		✓	*508	X
Timed reminder on		✓	*46	X
Timed reminder off		✓	#46	X
Toggle/connect	✓	✓	*2	X
Trace call		✓	*84	X
Transferring	✓			
Trunk flash		✓	*51	X
Uniform Call Distribution				
Log on		✓	*401	X
Log off		✓	#401	X
Available		✓	*402	X
Not available		✓	#402	X
Work on		✓	*403	X
Work off		✓	#403	X
UCD night on		✓	*404	X
UCD night off		✓	#404	X
Calls in queue		✓	*405	X
Use speed dialing		✓	*7	X
Change speed dialing (station)		✓	*92	X